


2.2M Garden Arch Instruction Manual

General information and safety warnings

- Wear gloves whilst assembling and disassembling.
- Do not hammer the stakes and arms,
- Do not exert too much force in case it alters the shape of the arch.
- Make sure that the stakes are inserted approximately 5 inches into the soil directly into the prepared ground. It is a good idea for stability to sprinkle some light gravel or pebbles around the trellis and plant on top of the soil.
- Do not use in adverse weather.
- Do not allow children to play with the trellis.
- Not suitable for commercial purposes.
- Make sure that the growth of the plants used are kept tightly pruned especially during windy seasons autumn and winter. If hardy plants are chosen, this will encourage fresh growth in the spring and add security to the arch.


Parts




Assembly

- Ensure that you have all parts as listed above.
- Remove all packaging and dispose of correctly.
- We recommend that 2 people assemble this garden arch.


1. Connect curved poles (A & B) together. Repeat this step twice so you have 2 curved poles.



2. Connect the 2 curved poles together using poles (C) and secure with screws (F). The 2nd person will need to support the weight of the top curved pole.



3. Connect 2 panels (D) together using screws and bolts (H). Repeat this step twice.



GUARANTEE IMPORTANT

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website

The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre. Due to continuous product improvement, we reserve the right to change the product specification without prior notice.