
Assembly Instruction



Warm Reminder

If you experience any issues with our product (including missing parts, damage, or not meeting expectations), please contact us. We'll ensure satisfactory assistance within 24hours.

General Guidelines

- Please read the following instructions carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us if further information or assistance is needed.


Notes

- The product is intended for indoor use only. It must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to the product may occur if the product is used outside of its intended purpose and/or if it has been changed/modified from its original design. The seller does not assume any responsibility or liability for injury or damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Assemble the item on a spacious surface and avoid placing the unwrapped product directly on the ground to prevent damage.
- Do not stand or sit on the wooden boards.
- Wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Match each part and fitting based on the part number in the manual.
- If a part does not match the fitting, please check the manual for clarification.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes, then tighten them one by one.
- Periodically inspect the screw tightness while the product is in use. Retighten if necessary to ensure structural integrity.
- If you accidentally spill water or any other liquid on the surface, immediately wipe it clean with a dry towel.
- Keep the product away from sharp, pointed objects and corrosive substances to prevent damage.
- Place the item on level, solid ground during use.


Warnings















- During assembly, keep all small parts out of the reach of children, as they may be fatal if swallowed or inhaled.
- Children should not climb or play on the product to avoid tipping over and causing serious injury.
- To avoid the potential danger of suffocation, keep all packaging materials (film, plastic bags, foam, etc.) away from babies and children.
- Do not shake or move the product violently during use to avoid tipping over.

Parts List(EN)














Parts List(EN)




1  1PCS	2  1PCS	3  Side A Side B 1PCS	4  Side A Side B 1PCS
5  Side A Side B 1PCS	6  Short 1PC	7  Long 1PC	8  2PCS
9  1PC	10  Short Side A Side B 2PCS	11  Long Side A Side B 2PCS	12  4PCS
13  564 138 4PCS	14  564 146 4PCS		

Parts List(EN)

No. A Quantity:20+2 Pcs Cam Lock Dowel 6*40mm 	No. B Quantity:20+2 Pcs Cam φ15 	No. C Quantity:12+1 Pcs Dowel 8*30mm 	No. D Quantity:4 Pcs Foot Pad Ø15*5 
No. E Quantity:4 Sets Handle 	No. F Quantity:4 Sets Flip cover accessories 	No. G Quantity:48 Pcs Sticker Ø20 	No. H Quantity:2 Sets Anti-falling Parts 
No. I Quantity:24+2 Pcs Screw M5*40mm 	No. J Quantity:1 Pcs Allen Key 3# 	No. K Quantity:56+4 Pcs Screw M3.5*14mm 	No. L Quantity:1 Pcs Screwdriver 
No. M Quantity:8 Pcs Flip cover accessories 26*17*9 	No. N Quantity:8 Pcs Flip cover accessories Ø26*11 	No. O Quantity:8 Pcs Flip cover accessories Ø19*11 	NO.P Quantity:8+2Pcs Screw M4*10mm 

Instructions For Fastening
CAM-BOLT and CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically




Shoulder is flushed (on the same level) with the panel.



Shoulder is above the panel.

Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.

INSERTING CAM-LOCK




Insert Cam-lock with arrow align to Cam-bolt head

CORRECT

WRONG


Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

TIGHTENING CAM-LOCK




Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.

STEP 1




Note: The "M" accessory needs to be distinguished from top to bottom, with the holed side facing down!!!



M×4PCS

Note: Please knock the accessory into the groove of the board.

STEP 2




Note: Please knock the accessory into the groove of the board.



N×4PCS

STEP 3




Note: The "M" accessory needs to be distinguished from top to bottom, with the holed side facing down!!!

Note: Please knock the accessory into the groove of the board.

	M×4PCS


STEP 4





Note: Please knock the accessory into the groove of the board.

	N×4PCS


STEP 5











Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.







	A×4PCS
	B×4PCS
	C×2PCS


STEP 6











Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.








	A×2PCS
	B×2PCS
	C×1PCS


STEP 7
















	A×2PCS
	B×2PCS
	C×1PCS

Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.


STEP 8










Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.






	A×2PCS
	B×2PCS
	C×1PCS


STEP 9


Please note: The panel marked with the number "8" should be assembled with the side that has the holes facing up.




	I×10PCS
	J×1PCS


STEP 10




	I×10PCS
	J×1PCS


STEP 11











Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.






	A×10PCS
	B×10PCS
	C×7PCS

STEP 12



	I×4PCS
	J×1PCS


STEP 13



Note: The pegs can be directly hammered into the board.


	D×4PCS

STEP 14




Left	F×4PCS
Right	F×4PCS
	K×8PCS

STEP 15




	K×24PCS


STEP 16



	K×16PCS


STEP 17



	E×4PCS


STEP 18

Note: When installing this step, it is necessary for two people to work together, one person to hold the door panel and the other person to tighten the screws.



	O×4PCS
	P×4PCS


STEP 19



	K×4PCS


STEP 20

Note: When installing this step, it is necessary for two people to work together, one person to hold the door panel and the other person to tighten the screws.




	O×4PCS
	P×4PCS

STEP 21



	K×4PCS

STEP 22



Note:
Please lift up the furniture by two people when moving is needed. Dragging may cause the legs failure.