


Package contents(parts are not to scale):



Light source

110V E26 9*40W MAX

Care and Cleaning

EXTERIOR MAINTENANCE

- 1.To clean the outside of the fixture,use a dry or slightly dampened clean cloth(use clean water,never a solvent)to wipe the surface of the fixture
2. Do not use any cleaners with chemicals,solvents or harsh sbrasives.Use only a dry soft cloth to dust or wipe carefully

INDOOR CHANDELIER INSTRUCTIONS GUIDE

8623-9C

CAUTION

Pre-Installation

PLANNING THE INSTALLATION

Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED:



Gloves




Spanner



Test pencil


Installation

Step 1



Installation (continued)

Step 2



Operation

- Turn on power at the circuit breaker or fuse box.
- Turn the light switch on to activate the fixture