

ASSEMBLY INSTRUCTIONS

Description: FIONA DINING CHAIR

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1	Chair Back		1
P2	Seat Frame		1
P3	Front Legs	at Co	2

Hardware List


Item	Description		QTY
H1	Bolts 1/4" x 1-1/2"	0	2
H2	Bolts 1/4" x 2-3/8"	0	4
Н3	Bolts 1/4 x 3"	1	4
H4	Lock Washers 1/4"	0	10
H5	Flat Washers 1/4"	0	10
Н6	Allen Key		1

DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.


Assembly Procedures:

*Assemble the Chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.




Step 2: Attach the Front Legs (P3) to the Seat Frame (P2) as shown below.

(H2)x4	Bolts 1/4" x 2-3/8"	<u> </u>
(H4)x4	Lock Washers 1/4"	0
(H5)x4	Flat Washers 1/4"	0
(H6)x1	Allen Key	



Step 3: Turn the assembled chair to an upright position. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase