



Installation Manual-

BV C04824
BV C04830
BV C04836

THANKS FOR WATCHING

Your feedback is invaluable to us and we would love to hear about your experience. Please take the time to leave us a review.



Thank you for shopping with us!


We encourage you to take a few minutes to go through this booklet. It contains important information on installation and care tips to keep your furniture looking as good as new.

Item NO.:BV C04824 / C04830 / C04836




Hardware

NO.	Draw	QTY	NO.	Draw	QTY
A	 Screws Ø4x14mm	48	I	 Hinges	4
B	 Two-in-one connector	26	J	 Handle	2
C	 Two-in-one connector	26	K	 Screws M4x18mm	4
D	 Wood plug	6	L	 Anti-collision gasket	4
E	 Plastic anchor(Ø10mm)	2	M	 Adjustable feet	4
F	 Screws for fix on the wall	2	N	 Bracket (14x14x28mm)	1
G	 Bracket (53x70x44mm)	2	O	 Screwdriver	1
H	 Bracket (19x19x35mm)	2	P	 Movable laminate support	4

Recommended tools




Dimensions



CARE CLEANING AND MAINTENANCE


- 1.Dust regularly with a soft , dry cloth.
- 2.Avoid the use of all chemicals household cleaners, abrasives, or cleaners that contain lemon, vinegar, or other acids that may damage the finish.
- 3.Excessive exposure to sunlight and extreme changes in temperature and moisture can damage wood furniture.
- 4.The sink top is resilient, but care needs to be taken to preserve its appearance.
- 5.Do not place hot appliances, such as curling irons and hot hair dryers directly on the countertop. Wipe spills immediately.

Step 14




Notes:
The installation position can be selected
according to the required height.


Finished




Dimensions




Components




Step 1




Step 2







Step 12





Step 13





Step 5



x2

G

($\varnothing 4 \times 14\text{mm}$)





x12

A



Tool

Step 7



x4

I

($\varnothing 4 \times 14\text{mm}$)




x24

A




Tool

You can adjust the doors by tightening or loosening the screws on the hinge. ➔



Step 6



x2

H



x1

N

($\varnothing 4 \times 14\text{mm}$)




x12

A



Tool

Step 8



x2

J



x4

K



x4

L



x4

M



Tool