


Instruction of Remote Control



正面

ON-OFF button: Illuminate the candle ON-OFF (Note: Before you use the Remote control, Switch the ON-OFF button at the bottom of the candles).

TIMER: Set ON/OFF Automatic TIMER feature, set 2H/4H/6H/8H. *For example, set 2H at 20:00, it will automatically shutdown at 22:00. Will be automatically open at 20:00 next day, at 22:00 then automatically shutdown, It will cycle every 24 hours.

MODE: Candle is NON-flicker Flame; Light is flicker flame.

Brightness control: Left button to lower the brightness, Right button to increase brightness.

More tips:
*Pull out the protectot sheet before use.
*If the battery of the Remote control runs out, you may pull out the battery tray then replace a new button cell battery.

Specifications

Material	Real Wax
Remote Control Range	5 Meter (16.4ft)
Battery Type	Requires 2×AA batteries per candle (batteries not includes)
LED lamp life	50,000 hours
LED Glow Time	250-300 hours (high-grade battery required; constant use of the timer may reduce battery life)

How to inserting the batteries

1. Open the battery compartment cover latch back and removing the cover completely.
2. Insert 2×AA batteries into the battery compartment according to the polarity indicators in side the compartment.
3. Close the battery compartment cover by placing the 2 small tabs in the slots and pressing down to secure the latch.

How to illuminating the candle

candle will illuminate until you manually move the switch to OFF.

Care and Maintenance

- Clean as needed with a soft, dry or slightly damp cloth.
- Keep out of direct sunlight, away from heat sources and out of extreme temperatures or your candle may soften or melt.
- * When not in use for an extended period of time, please remove the battery from the batteries.
 - * Use fresh batteries of the required size and type only. Do not insert mix old and new holder or in a lantern to protect furniture from was deposits.
 - * Place the candle on a protective base, on a candle holder or in a lantern to protect furniture from was deposits.
 - * Use fresh batteries of the required size and type only.

Cautions and Warnings

1. This candle is made of real wax and is flammable. Do not attempt to light this candle. Doing so could result in personal injury or damage to the light and its components.
2. Warning! This product contains small parts, which if removed, can pose a choking hazard. Keep away from small children.

Thank you for your purchase, your satisfaction is our greatest success!

背面

142*102mm
100000张

