


WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.



NOTE:

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

MAINTAINANCE AND WARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.




Weight Limitation

250LBS

PARTS LIST


Ax1

Seat



Bx4

Legs




HARDWARE LIST


SPARE

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.


ASSEMBLY INSTRUCTIONS



STEP 1: Open the zipper pocket under the seat and take the legs B out.




STEP 2: Place the Chair Back A on a clean padded surface.



Place the chair seat/back assembly on clean padded surface.

STEP 3 : Hold Chair Foot B in your hand, point it at the screw hole in seat A, and twist it several times until it is tightened.



Adjust levelers under legs to set the seat level.

STEP 4 : Assembly completed.