

CVAZER140

Assembly Instructions

CAUTION:

This lamp is partially assembled in the factory by qualified craftsmen. Some assembly is required before use. Please follow the assembly instructions carefully.

WARNING!-TO REDUCE

THE RISK OF FIRE,
ELECTRICAL SHOCK, OR

PERSONAL INJURY:

Never exceed maximum wattage indicated, as it may cause fire.

- Turn off/unplug lamp and allow to cool before replacing bulb.
- Do not touch bulb when fixture is turned on.
- Do not look directly at lighted bulb.
- Keep materials that burn easily away from lighted bulb.

Assembly:

- 1) Secure the Harp into Saddle
- 2) Place shade onto Harp and secure with
- 3) Finial.

Use only the bulb type and wattage indicated on the wattage label located near the socket.

CLEANING:

Use only soft cloth to dust and clean fixture. Never use chemicals or abrasive cleaners as it may damage finish.

Made In China

