



READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE


ASSEMBLY & INSTRUCTION MANUAL



PARTS







HARDWARE












x2






E x 2




D x 8

R x 1



C x 6



G x 1




N x 1



O x 1



S x 10



A x 4


F x 16

B x 8




C x 8

H x 16




T x 8



G x 16



x4



WALL

Ⓞ x 1



Ⓟ x 1



Ⓞ x 1

