


ASSEMBLY INSTRUCTIONS

Maui 4 Pc Outdoor Set

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.


PARTS LIST			
ITEM	DESCRIPTION	SKETCH	QUANTITY
HW1	Bolt and Washer M6*15		21 PCS
HW2	Bolt&Washer M6*30		12 PCS
HW3	Allen Key		1 PC
A	Chair Seat		2 PCS
B	Chair Backrest		2 PCS
C	Left Armrest		3 PCS
D	Right Armrest		3 PCS
E	Seat Cushion		2 PCS
F	Back Cushion		4 PCS
G	Sofa Seat		1 PC
H	Sofa Backrest		1 PC
I	Sofa Cushion		1 PC
J	Table Top		1 PC
K	Table Leg		2 PCS




ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until assembly is complete.


STEP 1




STEP 2




STEP 3




STEP 4





STEP 5



STEP 6



STEP 7**STEP 8**

CLEANING INSTRUCTIONS: clean with a soft cloth, brush or lightly vacuum.

ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll-free, customer service number and have this assembly manual open to the parts list ready to provide the model name, number and part name or number.

Customer Service

1-877-864-5752

8:30 AM PST - 4:00 PM PST (Monday-Friday)

Website: www.dwellhom.com

Missing Parts: parts@dwellhom.com

Warranty Information: www.dwellhom.com/warranty



WARNING: This product may contain small components, please ensure they are kept away from small children.