



Introduction

- ◎ **Product Name** : L-Shape Desk
- ◎ **Applications** : Bedroom, Living Room, Office, School
- ◎ **Product Dimension** : W140xD130xH72CM
- ◎ **Applicable Environment** : In an ideal environment, the temperature is between 18 °C - 28 °C / 64.4 °F-82.4 °F, the humidity is between 35% -65%.

Product Picture and Usage Notice

- ◎ The product display and disassembled as shown below :






L-Shape Desk

Users' Guide


Please read this guide carefully before installing and using furniture and keep it properly.

Installation Steps


Step1




Step2




Step3




Step4




Step5




Step6



Step7



Step8



◎ Usage Notice

1. During installation and use, please avoid product bumps.
2. Please avoid repeatedly assembling the product. Disassembling the product repeatedly will make it unstable.
3. For safer and more convenient installation, we recommend using power tools to install the product. In order to avoid product damage caused during installation, please use power tools carefully.
4. Please do not maliciously damage the product. ;

Precautions for Unpacking and Product Accessories List










◎ Precautions for Unpacking

1. Before unpacking, please check whether the product picture, name and model on the package are consistent with the product you purchased.
2. After unpacking, please check whether the product accessories in the package are complete.












◎ Product Accessories List:

1. Users' Guide

2. Hardware accessories are as follows: (mm)

| | | | | | | | |
|---|---|--------|-----|---|---|-----------|-------|
| A |  | Φ 5x32 | x20 | B |  | Φ 12 | x20 |
| C |  | Φ 8x40 | x6 | D |  | Φ 4x14 | x16 |
| E |  | | x8 | F |   | Φ 5x40/S3 | x24/1 |
| G |  | | x4 | H |  | | x24 |

3. Plate accessories are as follows: (mm)

| | | | | | |
|--|---|---|--|--|---|
| 1  300x1086 | 2  705x370 | 3  705x120 | 4  705x120 | 5  705x120 | 6  x2 298x400 |
| 7  x2 705x80 | 8  300x948 | 9  820x400 | 10  1000x480 | 11  400x480 | |