

Assembly Instructions

**Hickory Solid Wood
End Table, Coffee Table & Console Table
with Shelf**



Thank you for choosing our product.

We hope that this piece brings you many years of enjoyment!

For help with assembling your furniture,
or if you have missing hardware, please email us.

PARTS (included)

(A) Table Top (1)

(B) Table Legs (2)

(C) Shelf (1)



HARDWARE (included)

(a) 2¾" Bolts (4)

(b) 1½" Bolts (4)

(c) Allen Wrench (1)



STEP 1

Lay table top upside down on a clean surface. Place table legs on table top with notches on legs against the table skirting (see photo 1). Now insert 2¾" bolts through the brackets that are attached to the table skirting and turn into the inserts on table legs (see photo 2). Do not fully tighten the bolts until shelf is attached.




photo 1




photo 2

STEP 2

Get someone else to hold the shelf in place (see photo 3) while you align the holes in the leg crosspieces with the holes on the bottom of the shelf. Insert 1½" bolts through the crosspieces and turn them into the metal inserts on the shelf bottom (see photo 4). Now you are ready to tighten all the bolts using the Allen wrench provided. (Do not overtighten.) Once this is done set table upright and check for stability. If it rocks adjust levelers as needed (see inset photo). You should be able to turn these with your fingers. (If you cannot you may have to use pliers.)




photo 3





photo 4



inset photo