




Assembly Instructions




Caution: You must read this before you proceed

Dining Table








Part List

Label	Picture	Description	QTY
A		Left Table Top	1
B		Middle Table Top	1


C		Right Table Top	1
D		Table Leg	4
E		Vertical Apron	2

Hardware

Label	Picture	Description	QTY
①		Bolt Set (M8x70mm)	9
②		Bolt Set (M6x70mm)	11
③		Bolt Set (M6x30mm)	5
④		Allen Key (M5)	1
⑤		Allen Key (M4 Ball Long)	1

Assembly Preparation

Before
Beginning
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps


Overview



FRONT FACING


This Dining Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Place the Left Table Top(A), Middle Table Top(B), and Right Table Top(C), onto a clean, non-marring surface.
Align the Left Table Top(A), Middle Table Top(C) and Right Table Top(B) as shown above.

Step 2



- 2.1) Slide out the center apron and straighten it.
- 2.2) Push the Table Tops together
- 2.3) Make sure the Table Top is aligned correctly.


Step 3



Secure center apron to Middle Table Top(B) and Right Table Top(C) using Bolt Sets(②) with Allen Key(⑤).

Tighten the Bolts fully in a sequential manner.

Step 4




4.1) Align Vertical Apron(E) with the corner blocks and attach using Bolt Sets(③) with Allen Key(⑤).

4.2) Attach Vertical Apron(E) to Table Tops using Bolt Sets(②) with Allen Key(⑤).

Tighten the Bolts fully in a sequential manner.


Step 5



Attach Table Legs(D) to corner blocks using Bolt Sets(①) with Allen Key(④).

Do not fully tighten the Bolts.

Step 6



Stand the Table up, with assistance from your partner.

EXERT pressure, floorwards, onto the Table.

This pressure will help the Legs and Table Top reach alignment at all joints.

Check for wobbles on a level surface.

If no wobbles are found, in a sequential manner, gradually tighten all Bolts until evenly secured.

When tightening the Bolts tighten sequentially.

Do not tighten any Bolt fully and then move on towards the next one.

This could cause the frame to warp.





















If there are still wobbles, loosen the Bolts and excute the same process.

If the Table is not Stable it could lead to damage to the product.

Your Dining Table is ready for use.

This Dining Table can only be used on a flat, level surface.

Care & Maintenance

-   ● Do not put hot items directly on furniture surface
 -   ● Do not clean furniture with harsh cleansers or polish.
 -   ● Do not place furniture under direct sunlight.
 -   ● Do not place furniture near heating or cooling vents.
 -   ● Do not write on furniture without a padded barrier to protect the surface.
 -   ● Do not place furniture outside . For indoor use only .
 -   ● Not for commercial use. For residential use only .
 -   ● Stains may be removed with mild soap solution and damp cloth.
 -   ● Children should not climb or jump on the furniture.
-
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .