


ASSEMBLY INSTRUCTION

ITEM: N715P473930


DINING TABLE



IMPORTANT NOTE :

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP

Detail view



Part List

Hardware List

A




Table Top (1pc)

1



Ø1/4" x 35mm

Bolt (8pcs)


2



Ø1/4" x 13mm x 1.5mm

Spring Washer (8pcs)

B



Link Board (2pcs)

3



Ø1/4" x 16mm x 1.5mm

Flat Washer (8 pcs)


4



Ø5/16"


Half Moon Washer 2pcs)

C



Legs table (2pcs)

5



4 x 58mm

Allen key (1pc)

6



Ø5/16" x 80mm

Fully threaded bolt (2pcs)


7



Ø5/16" x 6mm

Hex nut (2pcs)

D



Stretcher (1pc)


8



Ø8 x 20mm

Wooden dowel (4pcs)


9




90 x 12mm

Open wrench (1pc)

Step 1





Step 2





1	Ø1/4"x35		8PCS	5	4x58		1PC
2	Ø1/4"x13x1.5		8PCS	8	Ø8x20		4PCS
3	Ø1/4"x16x1.5		8PCS				

Step 3





4	Ø5/16"		2PCS	7	Ø5/16" x 6mm		2PCS
6	Ø5/16"x80		2PCS	9	90 x 12mm		1PC

Step 4



Use the hardware removed in Step 1 to attach to the table top (A) by using an Allen key.

Step 5



Completed