

OUTDOOR WATER FOUNTAIN USER MANUAL

User Manual (English)

Model / SKU: _____ Color/Finish: _____ Date: _____

WHAT'S IN THE BOX

- Fountain body
- Submersible water pump
- Water tube (if included)
- LED light set (if included)
- Rainproof AC adapter / transformer + power plug (GFCI required)
- User manual



IMPORTANT SAFETY

- Use a covered Class A GFCI-protected outdoor receptacle.
- Unplug before moving, cleaning, or servicing.
- Keep the pump fully submerged. Never run the pump dry.
- Keep the adapter/transformer dry and elevated off the ground. Keep all connections dry.
- Do not use damaged cords, plugs, or parts.
- Tip: Create a drip loop on the cord before it reaches the outlet.



SETUP & OPERATION

Keep the water level above the pump at all times.

Step 1. Unpack & Position

Place on a flat, stable surface near a GFCI outlet. Keep upright.



Step 2. Inspect Parts

Confirm parts are included. Do not use if cracked or damaged.



Step 3. Open Back Cover

Remove back access cover (if included) to reach internal compartment.



Step 4. Connect Tube to Pump

Push tube firmly onto pump outlet. Ensure fully seated.



FINISH SETUP



Step 5. Place Pump Inside

Put pump in base basin. Route tube upward to top outlet.



Step 6. Connect Power / LED

UNPLUGGED + dry hands. Connect pump plug to the rainproof adapter. If LEDs, connect waterproof plug and hand-tighten. Keep adapter/transformer dry and elevated.



Step 7. Fill & Test

Add clean water until pump is fully submerged. Plug in and verify flow. Top off water as needed. Never run dry (check water level daily in hot weather).

PUMP & PLUG SPECIFICATIONS (text version)

Pump (Submersible)

Rated: 120V~ 0.195A 60Hz

Feature: Impedance Protected

Use: Indoor & outdoor use

AC Adaptor / Transformer (Rainproof, Class 2)

Input: 120VAC 60Hz 9W

Output: 12VAC 300mA

UL Listed: E471406

Efficiency Level: VI

Power Plug / Cord

GFCI: Use only with a covered Class A GFCI-protected receptacle.

Orientation: Keep unit vertical/floor-mount.

Keep dry: Do not place plug/connection points in standing water.

Use a drip loop.

TROUBLESHOOTING

- No water flow: add water; check tube; ensure pump submerged.
- Noisy/weak: add water; clean pump intake; remove debris; check kinks.
- Air lock: unplug; add water; gently tilt/shake underwater to release air; plug in again.
- LED off: re-seat waterproof connector; hand-tighten; check outlet.

CARE & STORAGE

- Replace water regularly to reduce algae.
- Clean pump every 2-4 weeks (more often outdoors).
- Freezing weather: unplug, drain, dry, store indoors.
- Mineral buildup: wipe with diluted white vinegar. Do not use bleach or harsh chemicals.