


Assembly Instructions




END TABLE

CAUTION: You must read this before you proceed.









CAUTION : This Table is NOT a TOY. Keep your child / children at bay in the process of assembly.
For turning / flipping the table and to prevent damage to the table, 02 persons may be needed to execute this action.

Parts List

No.	Picture	Description	Qty
A		Table Top	1
B		Shelf	1
C		Legs	4














Hardware

Table Hardware

No.	Picture	Description	Qty
①		Nut M6	5
②		Flat Washer M6.5/18x2mm	5
③		Bolts M6x15mm	5
④		Flat Washer M6/12x2mm	5
⑤		Allen Key	1
⑥		Y Wrench	1


Assembly Preparation

Before Beginning Assembly:

       		
	<input checked="" type="checkbox"/> Read instructions, cover to cover.	
	<input checked="" type="checkbox"/> Have 2 adults on hand for assembly.	
	<input checked="" type="checkbox"/> Do not assemble on flooring or carpet.	
	<input checked="" type="checkbox"/> Assemble on a clean non-marring surface (packing foam).	
	<input checked="" type="checkbox"/> Save all packaging until finished.	


Assembly Steps

OVERVIEW



This Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise the parts and steps before assembly.


Step 1



Unpack and place all parts on a clean, non-marring surface.

Assembly Steps

Step 2



Place the Table top (A) with the bottom face skywards, onto a clean, soft surface to avoid any scratches or damages to the product.

Attach the Legs (C) into the housings at the 4-corner of the Table Top (A).


Using the Nut (①) with Flat Washer (②), affix these nuts loosely by using Y Wrench (⑥), to assemble legs in position, as shown in the picture.

CAUTION : DO NOT OVER TIGHTEN.

OVER TIGHTENING COULD LEAD TO DAMAGE OF THE PRODUCT.

SLOWLY TIGHTEN UNTIL SECURE AND STABLE.

Step 3



Place the Table on its side.

Attach the Shelf (B) to the Legs (C), using the Bolts (③) with Flat Washer (④).


Affix these bolts loosely to position by Allen Key (⑤), as shown in the picture.

CAUTION : DO NOT OVER TIGHTEN.

OVER TIGHTENING COULD LEAD TO DAMAGE OF THE PRODUCT.

SLOWLY TIGHTEN UNTIL SECURE AND STABLE.

Step 4



You are now at the FINAL stage of this assembly.





















In a sequential manner, drive in and fully tighten all bolts.

Thereafter, turn the table right way up.

The table now is ready to be used.

Caution: This Table can only be used on a flat, level surface.

Care & Maintenance

-   Do not put hot items directly on furniture surface.
-   Do not clean furniture with harsh cleansers or polish.
-   Do not place furniture under direct sunlight.
-   Do not place furniture near heating or cooling vents.
-   Do not write on furniture without a padded barrier to protect the surface.
-   Do not place furniture outside. For indoor use only.
-   Not for commercial use. For residential use only.
-   Stains may be removed with mild soap solution and damp cloth.
-   Children should not climb or jump on the furniture.
-   Dust and pick-up spills using a clean, non-colored, lint-free cloth.

What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

