






Important!

Thank you for your purchase. Please open it carefully.


If you encounter any problems, please contact us.

Service tenet - to enable customers to enjoy high-quality service.







Left upper side panel A*1




Upper right side panel B*1




Upper back panel C*1




Lower left side panel D*1




Lower right side panel E*1




Lower back panel F*1




Top beam G*1




Middle beam H*1




Kick Plate I*1




Middle beam J*4




Top Panel K*1




Bottom Panel L*6




Door M*1



Door N*5




Standing leg O*4




Adjustable foot P*4



13/32"Screw Q*66




13/32"Screw R*4




Door Pivot Pin Shim\

S*6



Long





Set screw

T*2








Lock

U*6





1








M*4

3















M*4





M*8


















10




Q×5







11









12










- 1.U tilts to the left
- 2.Insert the left edge of the opening in the middle of the door into the groove on the left side of the handle
- 3.Press the right edge of the handle so that the right edge of the middle opening of the door is stuck in the right slot of the handle



Problems and Solutions

Question 1: when encountering uneven height of two door panels, adjust the bottom adjustment foot to make it flat.



Question2 : When the door is closed, it still protrudes outward.
That's because the door is made of steel plate and has stretchability.
You can adjust it according to the method shown in the picture.

