

ASSEMBLY INSTRUCTIONS

IMPORTANT **PLEASE READ BEFORE YOU CONTINUE FURTHER**

ASSEMBLY PREPARATION

1. Remove all packaging materials, staples, and packing straps from the carton.
2. Refer to the Parts List and Hardware List to ensure all parts and hardware are correct before starting assembly.
3. Place all wooden parts on a clean, flat, and soft surface (e.g., carpet or rug) to prevent scratches and damage.

SAFETY PRECAUTIONS

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE OF PLASTIC PACKAGING MATERIALS IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY

1. Ensure ample space for assembly and position the area close to where the product will be placed.
2. Assemble the product on a surface that will not scratch or damage the exterior gloss or finishing of the furniture.
3. Identify all parts, hardware, and quantities required for each step.
4. Avoid over-tightening any fittings during assembly, as this may cause damage.
5. Use hand tools only--DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always assemble the product on a flat, level surface.
7. Assembly requires two or more people--do not attempt to assemble the product alone, as there is a risk of injury.
8. Do not sit or stand on the partially assembled product. Use the product only for its intended purpose.

WARNINGS






1. This product is intended for indoor and household use only, and is not suitable for commercial use.
2. Hardware may loosen over time. Regularly check all connections and re-tighten as needed.
3. Dining chairs are designed for normal use with all four legs on the ground. Do not sit in the chairs with only two legs on the ground (e.g., tipping back, forward, or sideways), as this may stress and damage the chair legs.
4. Do not stand on the chair.



- DO NOT STAND ON THE CHAIR
- DO NOT SIT IN THE CHAIR WITH ONLY TWO LEGS







Please make sure you have all these parts before you start.

PART LIST


Ⓐ x 1pc 	Ⓑ x 1pc 
Ⓒ x 1pc 	Ⓓ x 1pc 
Ⓔ x 1pc 	Ⓕ x 1pc 

Please make sure you have all these parts before you start.

HARDWARE LIST


①x (2pcs +1) 	②x (4pcs +1) 	③x (4pcs +1) 
JCBC M6 x 40mm	JCBC M6 x 80mm	HEX NUT 5/16"
④x (10pcs +1) 	⑤x (10pcs +1) 	⑥x (4pcs +1) 
SPRING WASHER 5/16"	FLAT WASHER 5/16" x 16mm	PH SCREW R/S #8 x 45mm
⑦x 1pc 	⑧x 1pc 	⑨x (1pc +1) 
ALLEN KEY M4 (BALL SHAPE)	SPANNER 12.8mm	DOWEL M10 x 30mm
 NOT PROVIDED		

(Extra Hardware for spare use)




STEP 1


Please remove plastic cover at hanger bolt of Leg C & D before assembly.




STEP 2

1	 JCBC M6 x 40mm	2PCS
4	 SPRING WASHER 5/16"	2PCS
5	 FLAT WASHER 5/16" x 16mm	2PCS
9	 DOWEL M10 x 30mm	1PC

Step: 1a




Step: 1b




DO NOT fully tighten bolts (leave slightly loose).

STEP 3

2	 JCBC M6 x 80mm	4PCS
4	 SPRING WASHER 5/16"	4PCS
5	 FLAT WASHER 5/16" x 16mm	4PCS


DO NOT fully tighten bolts (leave slightly loose).




STEP 4

3	 HEX NUT 5/16"	4PCS
4	 SPRING WASHER 5/16"	4PCS
5	 FLAT WASHER 5/16" x 16mm	4PCS

DO NOT fully tighten Hex Nut (leave slightly loose).



STEP 5



Steps to Check and Fix Dining Chair Stability

1. Initial Check for Wobbles:

- Place the dining chair on a level surface.
- Check if the chair wobbles.
- If wobbling is detected, perform the Drop Test.

2. Lift the Dining Chair:


- Lift the chair 30mm to 50mm off the ground.
- Ensure your feet and toes are well away from the drop zone.
- Drop the chair freely and vertically so all four legs hit the ground simultaneously.
- This test helps realign all parts and gaps into their proper positions.

3. Tighten Bolts and Screws:


- Tighten all bolts and screws.
- Tighten bolts and screws sequentially, using an alternating pattern.
- Avoid fully tightening any bolt or screw at once, as this can cause the frame to warp.

STEP 6

6		4PCS
PH SCREW R/S #8 x 45mm		



Fully tighten the screw
but do not over-tighten.



STEP 7

