


TV STAND-N893P497047

Assembly Instructions - Please keep for future reference.



DIMENSIONS

width - 70.87inch

Depth - 15.75inch

Height - 15.75inch

Important - Please read these instructions fully before starting assembly.

Thank you for choosing *our products*.

1. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution.

Recommendations Before Beginning Assembly



- Read instructions, cover to cover



- Have 2-4 adults on hand for assembly depending on product size



- Do not assemble directly on flooring or carpet



- Assemble on a clean non-marring surface (example: packing foam)



- Save all packaging until finished

3. Assembly Notice:


- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the hardware spill in the box.
- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- IMPORTANT: When setting up your product, DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING. Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

Care & Maintenance

-   ● Do not put hot items directly on furniture surface
-   ● Do not clean furniture with harsh cleansers or polish
-   ● Do not place furniture under direct sunlight
-   ● Do not place furniture near heating or cooling vents
-   ● Do not write on furniture without a padded barrier to protect the surface
-   ● Do not place furniture outside. For indoor use only
-   ● Not for commercial use. For residential use only
-   ● Stains may be removed with mild soap solution and damp cloth
-   ● Children should not climb or jump on the furniture
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth

Caution










- This product contains small components. Please ensure that they are kept away from small children.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.



components - fittings

Please check you have all the panels listed below.












Note: The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.

			
① x 1pc		② x 1pc	
			
③ x 1pc	④ x 1pc	⑤ x 1pc	⑥ x 1pc
			
⑦ x 1pc	⑧ x 2pcs	⑨ x 2pcs	⑩ x 2pcs
			
⑪ x 4pcs	⑫ x 4pcs	⑬ x4pcs	⑭ x 4pcs
			
⑮ x 1pc		⑯ x 1pc	⑰ x 2pcs
			
⑱ x 2pcs			


components - fittings

Please check you have all the panels listed below.

Note: The quantitie below are the correchet amount to complete the assembly. In some cases more fittings may be supplied than are required.

 M6x35mm	 Φ15x9mm	 Φ8x30mm	 M3x12mm
A x 36pcs	B x 36pcs	C x 20pcs	D x 32pcs
	 M6x35mm		
E x 8pcs	F x 4pcs	G x 4pcs	H x 2pcs
 M4x25mm	 M4x25mm	 M4x14mm	
I x 4pcs	J x 16pcs	K x 24pcs	L x 1pc
 M6x30mm			 M4x20mm
M x 8pcs	N x 6pcs	O x 4pcs	P x 4pcs


Assembly Instructions




Assembly Instructions

STEP 1/SCHRITT 1/Étapes 1


·Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.




STEP 1 : Extend Slide



STEP 3 : Remove Runner





STEP 2 : Push Lever UP



STEP 2


orientation



		
D x16pcs	E x 8pcs	L x 1pc


Assembly Instructions

STEP 3



		
A x20pcs	C x 10pcs	L x 1pc


STEP 4




	
B x10pcs	L x 1pc

Assembly Instructions

STEP 5




STEP 6



B x10pcs	C x 10pcs	L x 1pc


Assembly Instructions

STEP 7



 M6x35mm		
F x4pcs	L x1pc	N x 6pcs


STEP 8




 M6x30mm	
M x 8pcs	L x1pc


Assembly Instructions

STEP 9



	
A x16pcs	L x1pc

STEP 10



		
B x16pcs	J x 16pcs	L x1pc

STEP 11

orientation

Runner

x2pcs

x2pcs

⑨

⑩

D

O



L

D x 16pcs	E x 8pcs	O x 4pcs	I x 4pcs	L x 1pc

Technical drawing of the TV stand assembly, showing the front view. The stand features two drawers on the left side, labeled 9, and two drawers on the right side, labeled 10. The drawers are shown in an open position, revealing the internal mechanism. The stand is supported by four legs, with the front legs being thicker and more prominent. The overall design is minimalist and modern.


Assembly Instructions

STEP 13




G x4pcs	K x 8pcs	L x1pc

STEP 14



When the hinges are installed, you can refer to the pictures to adjust crevice of the doors till it's perfect:



1. To adjust the doors up and down, please refer to step (a)
2. To adjust the distance between the doors and side panels, please refer to step(b)
3. To adjust the gap between two doors, please refer to step (c)
4. After the adjustment finished, please tight the screws, refer to step (d)

H x2pcs	P x4pcs	K x 16pcs	L x1pc