

ASSEMBLY INSTRUCTIONS FOR GRAZZI KITCHEN ISLAND

1/4 X 2 1/2
LAG SCREW
WITH
1/4 WASHER

3/8 X 2 1/2
LAG SCREW
WITH
3/8 WASHER

