


Welcome

Thanks for purchasing this **Electric Egg Cooker**. Please read this user manual carefully before use.



Operation Instruction

Boiled Egg

1. For the first time use, clean the surface of egg boiler heating plate, then add a proper amount of water for heating according to how many eggs to cook.
2. After put in the eggs on plastic eggs, put the cover and switch on the power. Indicator lights on.
3. It takes 10-15 minutes to boil the eggs and supports up to 7 eggs once.




1. Add appropriate amount of water into the heating plate.



2. Connect the power and switch on power button

Welcome

Thanks for purchasing this **Electric Egg Cooker**. Please read this user manual carefully before use.



Operation Instruction

Boiled Egg

1. For the first time use, clean the surface of egg boiler heating plate, then add a proper amount of water for heating according to how many eggs to cook.
2. After put in the eggs on plastic eggs, put the cover and switch on the power. Indicator lights on.
3. It takes 10-15 minutes to boil the eggs and supports up to 7 eggs once.



1. Add appropriate amount of water into the heating plate.



2. Connect the power and switch on power button



3. The egg cooker will automatically turn off when the eggs are ready



4. Pierce the end of the eggs



3. The egg cooker will automatically turn off when the eggs are ready



4. Pierce the end of the eggs

Steaming Egg Custard

1. Mix whole juice of eggs with salt or sugar and other seasoning, then pour into the egg cup.
2. Add water into heating plate, and put the prepared egg cup on the middle of egg rack.
3. Turn on the switch. Cooking time determines the tenderness of custards.

Cleaning & Maintenance

1. Only clean after unplugging the power cord.
2. Do not clean the heating plate with rough cleaning tools.
3. Do not immerse the main machine into water, otherwise it may damage the product.

Attention

1. US/UK Size Optional. Voltage (US): 110V/ 60Hz .Voltage (UK): 220V/50Hz
2. Do not open the transparent cover during cooking. Beware of being scalded by steam.
4. Do not move the product during cooking.
5. Place it out of reach of children.
6. Only used to boil eggs. Do not use it to cook coffee, tea or other things.
7. If the power cord is damaged, please do not continue to use.

Steaming Egg Custard

1. Mix whole juice of eggs with salt or sugar and other seasoning, then pour into the egg cup.
2. Add water into heating plate, and put the prepared egg cup on the middle of egg rack.
3. Turn on the switch. Cooking time determines the tenderness of custards.

Cleaning & Maintenance

1. Only clean after unplugging the power cord.
2. Do not clean the heating plate with rough cleaning tools.
3. Do not immerse the main machine into water, otherwise it may damage the product.

Attention

1. US/UK Size Optional. Voltage (US): 110V/ 60Hz .Voltage (UK): 220V/50Hz
2. Do not open the transparent cover during cooking. Beware of being scalded by steam.
4. Do not move the product during cooking.
5. Place it out of reach of children.
6. Only used to boil eggs. Do not use it to cook coffee, tea or other things.
7. If the power cord is damaged, please do not continue to use.