Assembly Instructions

CAUTION : You must read these Assembly Instruction before you proceed

Care & Maintenance




- Not for commercial use. For residential use only.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.




- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



- Stains may be removed with mild soap solution and damp cloth.




- Keep away from sources of ignition.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.



Please look into the Seat Panel for hardware packs.

SWIVEL CLUB CHAIR










CAUTION: This Swivel Club Chair is NOT a TOY
Keep your child / children at bay during the assembly process.
For turning the Swivel Club Chair and to prevent damage to the Swivel Club Chair, 2 adults may be needed to execute this action






Parts List

Label	Picture	Description	Qty
A		Left Armrest	1
B		Right Armrest	1

Parts List


Label	Picture	Description	Qty
C		Backrest	1
D		Front Rail	1
E		Seat Panel	1
F		Connector Rail	2
G		Leg Base	1
H		Seat Cushion	1
I		Back Cushion	1

Hardware:

No.	Picture	Description	Q.ty
①		Screw (M6*60mm)	9
②		Screw (M6*35mm)	5
③		Bolt (M6*40mm)	5
④		Bolt (M6*35mm)	5
⑤		Bolt (M6*20mm)	5
⑥		Washer	5
⑦		Allen Wrench	2

Assembly Preparation:


Before Beginning Assembly:




- Read instructions, cover to cover
- Have 2 adults on hand for assembly
- Do not assemble on the flooring or carpet
- Assemble on a clean, non-marring surface (packing foam)
- Save all packaging until finished.

Assembly Steps:


Overview:






This Swivel club chair has multiple parts and may require up to 45 minutes to assemble. To give you an overview of the Swivel club chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise the parts and steps before assembly.

Step 1:



Unpack and place all the parts on a clean, non-marring surface.


Step 2:



Please pay attention to the hole above follow the arrow


Fix the Front rail (D) and the 2 Connector rails (F) to the Left armrest (A) using 4pcs Screw (①) and Allen wrench (⑦).
DO NOT fully tighten the Screw.

Step 3:




Fix the 2 Connector rails (F) to the Left armrest (A) using 2 pcs Bolt（④）and Allen wrench (⑦).
DO NOT fully tighten the Bolts.

Step 4:




Fix the Front rail (D) and the 2 Connector rails (F) to the Right armrest (B) using 4 pcs Screw (①) and Allen wrench (⑦).
DO NOT fully tighten the Screw.

Step 5:



Fix the 2 Connector rails (F) to the Right armrest (B) using 2 pcs Bolt（④）and Allen wrench (⑦).
DO NOT fully tighten the Bolts .


Step 6:



Secure the Backrest (C) to the Left armrest (A) and the Right armrest (B) using 4pcs Bolt (③) and Allen wrench (⑦).

DO NOT fully tighten the Bolts.


Step 7:



Secure the Seat panel (E) to the Left armrest (A) and the Right armrest (B) using 2pcs Screw (②) and Allen wrench (⑦).


DO NOT fully tighten the Screws .

Step 8:




Secure the Seat panel (E) to the Front rail (D) using 2pcs Screw (②) and Allen wrench (⑦).
DO NOT fully tighten the Screws .

Step 9:




Secure the Leg base (G) to the 2 Connector rails (F) using 4pcs Bolt (⑤), 4pcs Washer (⑥) and Allen wrench (⑦).
DO NOT fully tighten the Bolts .

Step 10:



Place 1pc the Seat cushion (H) and 1pc Back Cushion (I) onto the Swivel Club Chair. Then affix the Magic Tape Straps as shown above.

Step 11:



Inspect it and make sure all parts are adequately connected.
Gently and gracefully, sit onto the all Swivel Club Chair .This will help to align all the parts at all joint areas.
Then get off the Swivel Club Chair and in a sequential manner, gradually tighten all Screws at all joints until evenly connected.
If there are still wobbles, loosen the Screws and execute this same process.
WARNING!! IF SWIVEL CLUB CHAIR IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.
Your Swivel Club Chair is ready for use.
This Swivel Club Chair can only be used on a flat, level surface.