




ASSEMBLY INSTRUCTION




Parts List:



Hardware List:

 Ax26	 Bx26	 Cx26	 M4x35mm Dx12	 M3x12mm Ex16	 M4x25mm Fx2
 Gx2	 Hx2	 Ix1			

1



Ax16




Ex8



Hx2


2





Cx4



Dx2



3




Bx3



Cx3

4




Bx3



Cx3

5




Bx2




Cx3

6



7




Bx8



Cx9

8



Ax10



Bx10



Cx4



Dx10




Fx2




Gx2

x2



9



10







11



1x1

12



1x1