


MANUAL INSTRUCTIONS

5 BOXES

COURTYARD GAZEBO

LOUVERED PERGOLA WITHOUT NETTING

12*9FT



CONTACT US:24H,Mon~Sun.

 service@kmcglobe-us.com

 (USA) +1 213-816-4788

CUSTOMER SUPPORT

Dear customer

Thank you for your purchase.

This product is a non-permanent outdoor structure designed and manufactured for personal use rather than commercial use.

Please confirm whether the installation is permitted in your states firstly.

1. When you receive the product, please make sure that all the boxes have arrived, and all the parts are intact.
2. Please browse the entire installation manual before assembling, retain this instruction manual for future reference.
3. If any problem occurs unsatisfactorily as follows:
 - Lack of boxes, or some boxes are not arrived.
 - The outer box is damaged.
 - The product is damaged / bent / cracked while you open the box.
 - The parts / accessories / assembly tools are missing.
 - The product is hard to assemble.
 - The instructions are not clear, or hoping for assistance with installation.
 - The product has functional problems.
 - The product did not meet your expectations.
 - Other aspects that you are not satisfied with.

Please feel free to contact us for help firstly. If there is any damage, please send us clear photos. We will check and do our best to provide the best solution for you. The missing or damaged parts will be delivered to you within 5 days.

**DO NOT RETURN YOUR UNIT TO THE STORE
CONTACT US FIRST**



service@kmcglobe-us.com



(USA) +1 213-816-4788

ATTENTION

PREPARATION :

The gazebo needs to be installed in cooperation with **three people**.

Estimated Assembly Time: **2-3 Hours**.

Site preparation suggestion: Level the ground surface,construct a wooden or concrete base as a foundation.

The following installation tools will be used.



2 m Adjustable Ladder



Tape Measure



Screw Driver



Pistol Drill



gradienter



Hammer






gloves





3 people

Minimum foundation size:



If your foundation is made of hardwood or concrete, Use an 10 mm diameter drill bit to drill holes in the foundation, with the depth exceeding 40 mm.



Use the expansion bolts that are pre-configured with the product to secure it in place. This installation methods will provide better wind resistance performance, extend the product's lifespan.

ATTENTION

CAUTION:

1. Tighten each bolt firmly and properly. Do not completely tighten the screws until all screws are started.
2. Some parts may contain sharp edges. Wear protective gloves in the box as necessary.
3. Children under the age of 16 should not be engaged in the assembly, removal or disassembly of the product.
4. It is strongly recommended to hire a professional installation team.

WARNING:

1. Children under the age of 10 should be supervised by a competent adult while using this furniture.
2. Please keep children out of the assembly area during assembly.
3. Never use this product as a support. Do not shake, lean, or climb on the product any time.
4. Please take appropriate measures to deal with the bad weather. Heavy rain, wind and snow may damage the gazebo. If necessary please dis-assemble and store for later use.
5. In snowy weather, please ensure that the thickness of snow on the roof does not exceed 5 inches. If it does, please remove the snow as soon as possible to ensure safety.
6. When the wind force reaches scale 8, please take corresponding measures to reinforce the gazebo to prevent it from being damaged by the wind, and be cautious of safety issues during strong wind conditions.
7. It is necessary to use anchor bolts, expansion bolts and ropes to fix the gazebo to the foundation for Long-term stability.
8. We offer a one-year warranty, excluding damages caused by improper installation, incorrect usage, failure to use the fixing accessories, unclean snow, or failure to take preventive measures.
9. Stay away from open flames.

PARTS LIST

- 1. Please ensure that all parts, accessories and installation tools are complete before starting the installation.
- 2. Due to the variety of accessories, some parts may be glued together, some parts may be trapped inside the larger ones, please check carefully.
- 3. In case you cannot find or lose some small parts or screws during installation, we have provided extra parts.
- 4. If any accessories are missing or damaged, please contact us immediately.

 service@kmcglobe-us.com

CARTON: A



A1 X 3



A2 X 1



E X 4



F X 4



G X 4



H X 2



I X 1



J X 2



K X 2



L X 2



M6x15mm
1 X 188 (+10)



M10x140mm
2 X 12 (+2)



M6x55mm
3 X 4(+1)



M10
4 X 1



M6
5 X 1



M5
6 X 1



M6x50mm
7 X 16



8 X 16



9 X 136(+10)



10 X 1

CARTON: B



B3 X 1



B4 X 1



B7 X 1

PARTS LIST

CARTON: C



B1 X 1



B2 X 1



B5 X 1



B6 X 1



D X 2

CARTON: D



C X 18


CARTON: E





C X 16





Before installation, please remove the wooden parts of the following components and remove the screw No. 2 for future use.



01 STEP X3




02
STEP



03
STEP

-  **B1** X 1  **B2** X 1  **B5** X 1
-  **B6** X 1  **H** X 2




-  **1** X 16

04 STEP




G X 2



2 X 4

05
STEP



Be sure not to tighten the screws.



06 STEP

B3


X 1

B4

X 1


L

X 2




07 STEP

Connect the lamp strip connectors on B1/B2 to the small connector on A2.




08 STEP

Connect the three interfaces with the same number to the connector.




Connect the thick connector on A2 to the interface.
L represents the light strip connector, and 1 and 2 are the motor connectors.



09 STEP



B7 X 1




Connect the two light strip interfaces on B7 to the small connector on A2.



1 X 4

10 STEP


Align the pulley assembly with the track.



11
STEP



K X 2




3 X 4

12 STEP



Pay attention to the position and orientation of the blinds.




13 STEP

 **I** X 1



Please do not power on when performing this step.

To facilitate the installation on the other side,
use the manual hook to fold up the blinds and check if they are installed correctly.
Keep them in the folded position.






14 STEP



C X 17

Pay attention to the position and orientation of the blinds.




9 X 68



1 X 68


Check if the sliding blinds are correctly installed.



16 STEP



D X 2




1 X 6

17
STEP

 **J** X 2

Suspension H type.





 **1** X 2

18 STEP









10 X 1





20 STEP



Hard foundation

Soft foundation

Installation Completed



To improve wind resistance, be sure to complete this installation step. If expansion screws or ground nails are not installed, strong winds may topple the gazebo. Expansion screws are essential for stability on cement surfaces and ground nails are for grassy surfaces. All are included in the accessories package.




7 X 16



8 X 16

Controller User Manual:



We sincerely thank you for choosing our products!
Please read this instruction manual carefully before using this product to ensure correct operation and prolong its service life.
Especially, please be sure to read the safety precautions before use.
After reading, please keep this user manual properly for future reference.


Safety precautions:



Warning: Indicates a potentially hazardous situation that, if not avoided, may result in death or serious injury.

- Do not throw this product into a fire, squeeze, puncture, or place it in high-temperature environments beyond the specifications outlined in this manual.
- Please do not disassemble or modify this product.
- Please do not charge this product in places where flammable and explosive materials are present.
- This product does not contain any repairable parts inside. Please do not disassemble or attempt to repair it yourself. If there is a malfunction, please contact the manufacturer or dealer.

Product appearance and functionality:



function	Instructions	
	Press and hold for two seconds to turn on (the SYS light will continuously illuminate in green). Press and hold for two seconds to turn off (the SYS light flashes red and then goes off).	
left motor	  Switch the channel to "1".	 open  close  stop
right motor	  Switch the channel to "2".	 open  close  stop
dual motor	  Switch the channel to "0".	 open  close  stop
light	  Switch the channel to "L".	 Three-level adjustable light intensity (high, medium, low)  Three color temperature settings (natural light, warm light, white light)  stop
light		Short press the button to cycle through low, medium, high, and off lighting levels

AFTER-SALE

AFTER-SALE SERVICE

If you have any suggestions or encounter quality issues with our products, please contact us first.

Our after-sales team will respond within 24 hours, and we will do our best to provide a solution until you are satisfied.

GUARANTEED CUSTOMER SERVICE

Your shopping experience is very important to us!

If you feel unsatisfied or have any questions,
just contact us!

If you want to share how wonderful our smart product makes your home, **just contact us** and share your pictures!

For further information,
just contact us!



 service@kmcglobe-us.com

 (USA) +1 213-816-4788