







SHOOTOUT SHOWDOWN


BASKETBALL




PARTS IDENTIFIER

1 Basketball Backboard  x1	2 Pole with Hinge - Left  x1	3 Pole with Hinge - Right  x1	4 Pole - Left / Front Foot  x1
5 Pole - Right w/ Front Foot  x1	6 Pole - Straight  x2	7 Pole - H  x1	8 Pole - Straight - Crimped  x1
9 Pole - Straight w/ Pin  x2	10 Pole - Telescoping  x2	11 Pole - L  x2	12 Pole - L w/ Pin  x2
13 Pole - L w/ Back Foot  x2	14 Pole - U  x1	15 Basketball Net Filet de basketball  x2	16 Ball Return Renvoi de ballon  x
24 Rim Anneau  x2	25  x1	60 Bolt - Small  x2	61 Bolt - Medium  x8
62 Bolt - Large  x8	63 Screw  x2	64 Washer  x22	65 Nut  x14
66 Spacer  x4	67 Allen Key  x1	68 Wrench  x1	80 Basketball  x4
81 Pump  x1			


1



2



3




4




Only fasten the bottom two holes with the Nuts and Bolts at this stage.


Pour l'instant, ne fixer que par les deux orifices du bas avec les vis et écrous.



5




Do not overtighten Bolts.
Ne pas trop serrer les vis.




6

NOTE: Do not Overtighten Bolts.


N.B. : Ne pas trop serrer les vis.




7



NOTE: Please make sure the pin locks into the hole with a "CLICK" sound.
N.B. : S'assurer que les boutons-poussoirs se verrouillent avec un déclic.




8



Step 4 Assembly
Assemblée de l'étape 4


9




Make sure the Pin Attachment ring faces inward.
S'assurer que l'anneau de la goupille est à l'intérieur.

! Do not overtighten Bolts. Repeat for both sides.
Ne pas trop serrer les vis. Répéter pour l'autre côté.

Extend the pole and lock with pin.
Allonger le poteau et le bloquer avec la goupille.




10




! Fasten the Backboard to the Frame. Only Bolt on the Top 2 Bolts. DO NOT overtighten Bolts.
Fixer le panneau au cadre uniquement avec les deux vis du haut. Ne pas trop serrer les vis.


11




12




13




14



15



16




17



18



FIG.10



WARNING:

- 1) Requires 3 "AAA" batteries (not included).
- 2) Batteries must be installed according to the correct polarization (+ and -).
- 3) Different types of batteries or new and used batteries are not to be mixed.

How to play

1. While game is in sleep mode, if a basketball is scored, the game will turn back on and the score board will begin the 5 sec. countdown.
2. After finishing the game, Turn OFF the scorer by using the ON/OFF switch.
NOTE: After being idle for 5 minutes, the scoreboard will turn off automatically.
However, we recommend turning the ON/OFF switch to OFF when the game will not after 5 minutes, if not in use, however, we recommend turning the ON/OFF switch to OFF when the game will not be used for an extended period of time.

YOU ARE NOW READY TO PLAY!