


User's Manual



TYD-XH-001


Attention

- ◆ The light source of stars and nebulae is strong, so eyes should not look directly at the light source.
- ◆ The projection direction can be adjusted by adjusting the Angle of the STAR RIVER STARRY PROJECTOR LAMP's sphere . When the projection Angle reaches the maximum Angle, don't continue to adjust the Angle of the sphere, otherwise the lamp may be damaged.
- ◆ This light source is a non-replaceable light and the entire fixture should be replaced when the light source reaches the end of its life.
- ◆ **Highlight Note:** ⚠

The brightness of the stars (laser brightness) is greatly affected by the ambient temperature and use time, and the laser operating temperature is 10°-40C;


When the ambient temperature is lower than 10°C, the laser cold start time is longer,and it is possible that the stars will not be seen when you first turn it on. but the stars will gradually returns to normal after a few minutes of turning on;

When the ambient temperature is hot, the laser projector will inevitably dim after working for a long time (the laser itself will heat up when working).At this time,please turn the lights off and release its heat (usually it takes more than 15 minutes to dissipation heat).Then restart the star projector to restore normal brightness.



The projection direction can be adjusted by adjusting the Angle of the STAR RIVER STARRY PROJECTOR LAMP's sphere

Host Key Operation Instructions




Note: The product needs to be connected to the power cord for use.

- ◆ **Power Switch:** Short press the power switch to turn off the equipment, and the stars and mixed color nebula are turned on by default after turning on.Press and hold the power switch to turn off the equipment.
- ◆ **Nebula Switch:** Short press the Nebula button to switch the color of the nebula, each time you press to switch a color, and so on; long press to turn off the Nebula function, and then short press to turn on the Nebula function again.
- ◆ **Star Switch:** Short press the key to switch the respiratory rate of a star each time.There are three modes of star breathing rate, namely "star breathing slow", "star breathing fast" and "star steady on". Long press to turn off the star function. After turning off, short press again to turn on the star function.
- ◆ **Ambient Light Switch:** Short press the switch to turn on Ambient Light. Short press to switch colors and long press to turn off the Ambient Light .
- ◆ **Timing Indicator:** After pressing any timing button on the remote control, the timing indicator light will be on, and the indicator light will be off when the timing is turned off.

面

Remote Control Instructions



- ◆ **Switch:** Short press the switch to turn on, and Nebula and Stars light are turned on by default after turning on; short press the button again after turning on to turn off
- ◆ **Ambient Light Switch:** Short press the switch to turn on Ambient Light. Short press to switch colors and long press to turn off the Ambient Light .
- ◆ **Nebula Brightness+:** There are 5 levels of Nebula brightness. The default brightness is the middle level. Each time you press it, the brightness will increase by one level.
- ◆ **Nebula Color Switching:** Each time you press the button, the nebula will switch to one color. After a cycle, it will return to the default color. Long press the button to close the nebula. After closing the nebula, short press the button to reopen the nebula.
- ◆ **Nebula Change Speed-:** Nebula change speed is divided into five gears 0-1-2-3-4; gear 0 is static, gear 4 is the fastest changing speed, and the default gear is gear 2. Every time you press it, the speed of Nebula changes by one level until it reaches level 0.
- ◆ **Nebula change speed+:** The change speed of the nebula increases by one level each time you press it, increase one step to 4.
- ◆ **Nebula Brightness-:** There are 5 levels of Nebula brightness. The default brightness is the middle level. Each time you press it, the brightness will decrease by one level.
- ◆ **Star Mode 1:** Star breathing rate slow mode.
- ◆ **Star Mode 2:** Star breathing rate fast mode.
- ◆ **Star Switch:** The default brightness is the brightest. When the brightness is dimmed, press this button once to increase the brightness by one gear until the brightest gear.
- ◆ **45-Minute Timing:** After pressing this button, the equipment enters the 45-minute timing, and emits a prompt tone "drop", at the same time the timing indicator lights up blue.Long press to cancel timing and indicator light off.
- ◆ **90-Minute Timing:** After pressing this button, the equipment enters the 90-minute timing, and emits a prompt tone "drop" ,at the same time the timing indicator lights up red.Long press to cancel timing and indicator light off.

Material:ABS/PC
Laser Class :CLASS I
Rated Voltage:5V≈1A
Rated Power:5W
Control Mode:Remote control
Remote Control Range:<5meters(Best distance)
Product Size:150*131*134mm
Applicable Environment:Indoor Home(Better in a dark environment)
Working Temperature:10°~40°Celsius



Do not look directly at the laser light source!
This is not a toy, children should not use it alone, please use it with an adult!

