




OPEN SHELF WITH DRAWERS



USER MANUAL



Contents


TOPIC	PAGE
01	
SAFETY INSTRUCTIONS	01-01
1-1	Thank You For Choosing Our Product 01
1-2	Precautions 01
02	
INSTALLING MODULES	02-31
2-1	Disassembly Diagram 02
2-2	Parts List 03
2-3	Assembly Instructions 04-31
03	
CUSTOMER SERVICE	32
3-1	30-Day Return Policy 32
3-2	1-Year Warranty 32
3-3	Quick Response Within 24 Hours 32
04	
PROBLEMS YOU MAY ENCOUNTER	33
4-1	Problems You May Encounter 33

Safety Instructions

Thank You For Choosing Our Product

Before assembly, please read this USER MANUAL first, and check according to Parts List to make sure all parts are included. Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority!


Precautions




- Avoid long-term direct sunlight exposure.



- Keep away from sharp objects.




- Keep away from heat.



- Keep infants/children away from assembly parts to avoid choking and suffocation.




- Keep away from corrosive substances.



- Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.

Helpful Tips



Drill Setting Guide

For easier installation, we recommend using a power drill; please set it to low speed gear 1 and adjust the torque to 4–10 to avoid excessive torque that may cause screw stripping and panel cracking.



Speed 1
(low speed)






Set Torque to 4–10

Disassembly Diagram


Package includes
two units;
diagram shows
one unit only.






















2Pcs



Parts List

For ease and safety, we recommend two people for assembly.



A x2 	B x2 	C x2 	D x2 	E x2 
F x2 	G x2 	H x2 	I x4 	J x2 
K x2 	L x2 	M x4 	N x4 	O x4 
P x4 	Q x4 			
1 x79  3 Spares	2 x79  3 Spares	3 x9  1 Spare	4 x31  3 Spares	6 x9  1 Spare
10 x35  3 Spare	13 x4 	17 x1 		


Assembly Instructions



Choose your setup before assembly: the cabinets can be installed either on the inner side or outer side of the height-adjustable desk


Inside setup:

Follow steps on pages 05-17 (marked “Inside”).



Outside setup



Follow steps on pages 19-31 (marked “Outside”).



Assembly Instructions

For the following steps, assemble both cabinets simultaneously: the left diagram shows installation on the left side of the desk, and the right diagram shows installation on the right side of the desk.

Inside-1




B x2	C x2	E x2	F x2	I x4	J x2	1 x48
----------------	----------------	----------------	----------------	----------------	----------------	-----------------

Assembly Instructions


Inside-2

Make sure the holes indicated by the arrows on Panels L and F are on the same side.


F x2		2 x4	
L x2		17 x1	





Align two boards
Insert cam bolt



Arrow points to cam bolt
Press cam lock





Use a screwdriver
Tighten clockwise



Inside-3





Note: Make sure the notch on part D, indicated by the arrow, faces upward.



D x2		4 x4	
----------------	---	----------------	---




Assembly Instructions

Inside-4




Inside-5


Note: Install part J on the side opposite part L.



Align two boards



Press cam lock



Tighten clockwise






Assembly Instructions

Inside-6

When assembling the left cabinet, attach the assembled unit from Step 5 to parts C and I.

When assembling the right cabinet, attach the assembled unit from Step 5 to parts B and I.




B x1		2 x12	
C x1		17 x1	
I x2			







Assembly Instructions

Inside-7

Note: Check the arrow-indicated holes to install panels G and H correctly.



Inside-8







Assembly Instructions

Inside-9


K x2	
3 x4	
4 x4	

Kx2




Inside-10


E x2		17 x1	
2 x8			





Align two boards
Insert cam bolt



Arrow points to cam bolt
Press cam lock




Use a screwdriver
Tighten clockwise



Inside-11

Place the assembled left cabinet at the left desk leg and the assembled right cabinet at the right desk leg.





Assembly Instructions

Inside-12

For the left, connect the assembled Part B to the left cabinet from Step 11.



For the right, connect the assembled Part C to the right cabinet from Step 11.



Assembly Instructions

Inside-13





Attach one part I to the left cabinet and the other to the right cabinet.



Assembly Instructions



Inside-14

To fit inside and outside installation, Part A has extra holes for fastener ①. Install Part ① in the position shown.





Inside-15

Left part A connects to the left cabinet; right part A connects to the right cabinet.



Assembly Instructions



Inside-16








x4

Inside-17

When installing Panels O, P, and N, ensure the grooved edges are aligned on the same side.



x4







Assembly Instructions

Inside-18



Step1: Pull out the slides on Part B and C.

Step2: Align and snap the slides on both sides into place.

Step3: Push the drawers in fully to complete installation.



Inside-19




Assembly Instructions



Choose your setup before assembly: the cabinets can be installed either on the inner side or outer side of the height-adjustable desk


Inside setup:

Follow steps on pages 05-17 (marked “Inside”).



Outside setup



Follow steps on pages 19-31 (marked “Outside”).



Assembly Instructions

For the following steps, assemble both cabinets simultaneously: the left diagram shows installation on the left side of the desk, and the right diagram shows installation on the right side of the desk.

Outside-1




B x2	C x2	E x2	F x2	I x4	J x2	1 x48

Assembly Instructions


Outside-2

Make sure the holes indicated by the arrows on Panels L and F are on the same side.


F x2		2 x4	
L x2		17 x1	





Align two boards
Insert cam bolt



Arrow points to cam bolt
Press cam lock





Use a screwdriver
Tighten clockwise



Outside-3





Note: Make sure the notch on part D, indicated by the arrow, faces upward.



D x2		4 x4	
----------------	---	----------------	---




Assembly Instructions

Outside-4




Outside-5


Note: Install part J on the side opposite part L.



Insert cam bolt



Press cam lock









Tighten clockwise

Assembly Instructions

Outside-6

When assembling the left cabinet, attach the assembled unit from Step 5 to parts B and I.



When assembling the right cabinet, attach the assembled unit from Step 5 to parts C and I.







Assembly Instructions

Outside-7

Note: Check the arrow-indicated holes to install panels G and H correctly.



Outside-8






Assembly Instructions

Outside-9


K x2	
3 x4	
4 x4	

Kx2




Outside-10


E x2		17 x1	
2 x8			





Align two boards
Insert cam bolt



Arrow points to cam bolt
Press cam lock




Use a screwdriver
Tighten clockwise



Assembly Instructions

Outside-11

As shown, place the assembled left cabinet at the left desk leg and the assembled right cabinet at the right desk leg.





Assembly Instructions

Outside-12

For the left, connect the assembled Part C to the left cabinet from Step 11.


For the right, connect the assembled Part B to the right cabinet from Step 11.



Assembly Instructions





Outside-13

Attach one part I to the left cabinet and the other to the right cabinet.




Assembly Instructions


Outside-14 To fit inside and outside installation, Part A has extra holes for fastener ①. Install ① at the positions shown.




Outside-15 Left part A connects to the left cabinet; right part A connects to the right cabinet.





Align two boards
Insert cam bolt



Arrow points to cam bolt
Press cam lock





Use a screwdriver
Tighten clockwise



Assembly Instructions

Outside-16




x4


Outside-17

When installing Panels O, P, and N, ensure the grooved edges are aligned on the same side.

1




2







x4

3



4







Assembly Instructions

Outside-18



Step1: Pull out the slides on Part B and C.

Step2: Align and snap the slides on both sides into place.

Step3: Push the drawers in fully to complete installation.



Outside-19





30 DAY Return Policy

If you're not completely satisfied with your purchase, please return the merchandise via our Official Customer Support. Unused merchandise can be refunded or exchanged within 30 days of purchase.



1-Year Warranty

We guarantee your product is free from defects in product material and workmanship for one (1) year starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new one. Replacement is free and all shipping costs are covered.



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
Whole Product	Parts are missing, defective or having wrong parts in package.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	Having issue(s) while reading the instruction or completing the assembly.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	Encountering non - human caused damage during use.	If the product is damaged due to non - human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Furniture Surface	Surface is broken, scratched or lack of some screw holes.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	The screw holes that on the board and the frame don't line up.	1. Tighten the screws only 70% of the way. Do not fully tighten the screws until all parts are aligned. 2. Adjust the board and frame until the holes align, then fully tighten all screws.
	Surface is uneven or not tight that has gaps after being assembled.	1. Loosen the screws in the uneven or gap positions; adjust until the surface is flat and tight, and then tighten the screws. 2. If your problem still can't be solved, please feel free to contact us.
Structure Frame	Components are bent, broken, chipped, rusted, or damaged.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	The furniture is unstable after being assembled.	1. Check if all screws are fully tightened. 2. Read through the manual and check if any parts are installed incorrectly or missing. 3. If the problem persists, please contact us.
	Encountering non - human caused damage during use.	If the product is damaged due to non - human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.

We are committed to providing our customers with premium
quality products and convenient customer service.

MADE IN CHINA