

## ASSEMBLY INSTRUCTION DINING TABLE

## IMPORTANT NOTE:


BEFORE YOU BEGIN, PLEASE READ AND FOLLOW THE ASSEMBLY INSTRUCTIONS CAREFULLY.

- IDENTIFY AND SEPARATE ALL PARTS BEFORE DISCARDING PACKAGING.
- PLACE WOODEN PARTS ON A CLEAN SOFT SURFACE TO AVOID SCRATCHING THE PARTS.
- DO NOT USE POWER TOOL FOR ASSEMBLY.
- AS WITH ALL FURNITURE, OCCASIONALY CHECK TO INSURE HARDWARE IS TIGHT





ATTACH THE TABLE LEGS (B) TO THE CORNER BLOCK WITH HEX SCREW (C) SPRING WASHER (F) AND FLAT WASHER (D). TIGHTEN THE HEX SCREW (C) BY USING THE HEX WRENCH (E).





## ASSEMBLY INSTRUCTION DINING CHAIR

## IMPORTANT NOTE:


BEFORE YOU BEGIN, PLEASE READ AND FOLLOW THE ASSEMBLY INSTRUCTIONS CAREFULLY. IDENTIFY AND SEPARATE ALL PARTS BEFORE DISCARDING PACKAGING.


- PLACE WOODEN PARTS ON A CLEAN SOFT SURFACE TO AVOID SCRATCHING THE PARTS. DO NOT COMPLETELY TIGHTEN SCREWS UNTIL AFTER STEP 7.
- DO NOT USE POWER TOOL FOR ASSEMBLY.
- AS WITH ALL FURNITURE, OCCASIONALY CHECK TO INSURE HARDWARE IS TIGHT





\* DO NOT USE POWER TOOLS FOR ASSEMBLY STEP 1





PAGE 2 OF 3

