

TORCHIERE FLOOR LAMP WITH GLASS SHADE

PACKAGE CONTENTS

- A. Upper Body
- B. Pole
- C. Pole with Touch Control
- D. Pole
- E. Pole
- F. Pole
- G. Lamp Base
- H. Remote Control

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter this plug. Save these instructions for future reference.

PREPARATION

Before beginning assembly and installation of product, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.

Lay out all lamp parts from box and put them on a flat surface.

ASSEMBLY AND INSTALLATION INSTRUCTIONS

Start assembly from top to bottom:

1. Screw upper body (A) onto pole (B) clockwise to tighten.
2. Screw pole (B) into pole with touch control (C) clockwise to tighten.
3. Screw pole with control (C) into pole (D) clockwise to tighten. Pull any excess cord gently through the poles so that these parts fit.
4. Screw pole (D) into pole (E) clockwise to tighten.
5. Screw pole (E) into pole (F) clockwise to tighten.
6. Screw pole (F) onto lamp base (G) clockwise to tighten
7. Plug lamp cord into adapter cord.

TOUCH CONTROL

TURN ON: Short press.



3 COLOR TEMPERATURE SETTING: Then short press the button again. 3000K, 4000K, 5000K.

BRIGHTNESS SETTING: Long press to enhance the brightness. Press and hold again to decrease.

REMOTE CONTROL

-Can easily control the floor lamp in a 32.8ft / 10m distance range

-Remote control is magnetic, can be stored or attached on lamp pole or steel surface.



CARE AND MAINTENANCE

Clean with soft dry cloth. Do not use abrasives.