



Please check that all fittings are available and in good condition before assembly.
If you have any questions, please contact us , we will solve your problem in the first time.


PARTS LIST

Ax1 	Bx1 	Cx1 	Dx1 	Ex4 	Fx4 	Gx1 
Hx4  M6x15mm	Ix8  M6x18mm	Jx4  M6x25mm	Kx1  M6x30mm	Lx4  M8x15mm	Mx1 	


ASSEMBLE INSTRUCTION

1

Tighten the screws to 100%.




2




Tighten the screws to 100%.

3




Make sure the screw holes on opposite legs are in one line.

4




Tighten the screws to 50%.

5




Tighten the screws to 50%.

6




Tighten the screws to 100%.

7



8



9

