


Installation Manual

MG-CC-M-WH-001

Assembly Instructions - Please keep for future reference



**Contact our professional
customer support at:
tlskyservice@outlook.com**

Important – Please read these instructions fully before starting assembly



Safety and Care Advice


Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.



Do not use an electric drill when installing the desktop! Please use the tools provided in the package.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable for your wall type




tlskyservice@outlook.com

Note

In order to enhance product durability, extend its lifespan, improve your user experience, and save time, we provide the following suggestions to assist you with the assembly process:

1. Please follow the installation steps to avoid unnecessary effort or assembly failures.
2. We suggest checking all screws every six months to ensure they are secure. If any screws are loose or if there are signs of rust, severe deformation, or wear, please tighten or replace the components promptly to maintain product performance and extend its lifespan.




No matter what problem you encounter, it is recommended to try our after-sales service first. Sending your question to the service staff in the form of a picture or video will help the service staff better understand your question so that they can better help you. Returning a product is a very difficult thing to do, before you decide to return it, please contact the service staff, a refund and a brand new product will be better options.



tlskyservice@outlook.com
















Person Recommended




Components - Fittings

Please check the listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

(A)  6x38mm x22	(B)  φ15x12 x22	(C)  M3.5x14mm x41	(D)  x4
(E)  x4	(F)  φ8 x8	(G)  4x14 x1	(H)  4x18 x2
(I)  x4	(J)  J1 J2 x1	(K)  x1	(L)  x8
(M)  x2	(N)  6x35mm x8	(O)  φ15x10 x8	(P)  x2
			

Ruler - Use this ruler to help correctly identify the screws




Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3





Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.

4




Make sure to put one carpet or some thicker film under the cabinet body during the installation in order to avoid scratch or damage to the parts.




tlskyservice@outlook.com


Way of using hinges



Before assembly
determine the position of the door
the oval hole on the hinge could
adjust door UP & DOWN



Turn the screw
at the end of the hinge
adjust door FRONT & BACK




Turn the screw
at the middle of the hinge
adjust door LEFT & RIGHT





















tlkservice@outlook.com

Assembly Instructions







Assembly Instructions

①  1	⑦  1	⑬  1
②  1	⑧  1	⑭  1
③  1	⑨  2	⑮  1
④  1	⑩  1	⑯  1
⑤  1	⑪  1	⑰  1
⑥  1	⑫  1	⑱  2

Assembly Instructions




Step 1



A		X6
B		X2

Assembly Instructions




Step 2



A		X4
B		X2



Assembly Instructions

Step 3



Assembly Instructions





Step 4



A		X4
B		X4
F		X2



Assembly Instructions

Step 5



Assembly Instructions

Step 6






B




X2

Assembly Instructions


Step 7



A		X8
B		X8
C		X3
F		X4
J1		X1






Assembly Instructions

Step 8









Assembly Instructions

Step 9







Assembly Instructions

Step 10






Assembly Instructions

Step 11



Assembly Instructions






Step 12



D  X4


Assembly Instructions

Step 13



Assembly Instructions

Step 14




ATTENTION

We will provide our best customer support.

If you have any questions or issues during installation, please send an email (see below) with your telephone number and address. We will provide installation support, guided videos and offer reissues for any defective parts. All queries will be addressed within 24 hours.

Customer satisfaction is of the utmost importance to us!



**Contact our professional
customer support at:
tlsskyservice@outlook.com**