


MANUAL INSTRUCTION

Cushion set



Cushion set

We offer a diverse range of products
to meet the needs of customers.

Reach us at

 service@kmcglobe-us.com

 (only us)+1 213-816-4788



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

⚠ WARNINGS

- For your safety be sure to read all instructions carefully.
- It is not fire proof. The fabric will burn if left in continuous contact with any flame source.
- The application of any foreign substance to the shelter fabric may render the flame resistant properties ineffective.
- **CARBON MONOXIDE POISONING.** We do not recommend the use of heaters or heat sources that consume oxygen to be used in this ice fishing shelter. The use of heating sources is a fire and a carbon monoxide hazard.
- Exercise extreme caution when using fuel-powered lanterns or heaters inside the shelter. Use battery-operated lanterns whenever possible.
- Be sure you have adequate fresh ventilation, including open windows and doors. All vents must be opened when using fuel-based heaters in your shelter.
- If you are fishing and falling asleep intermittently, turn off all lanterns and heaters.
- Never leave the ice shelter unattended.

PACKING LIST

- | | |
|-----------------------|---------------------|
| ▪ Shelter Carry Bag | ▪ Ice Anchor Bag |
| ▪ Ice Fishing Shelter | ▪ 8 * Ice Anchors |
| ▪ Instruction Sheet | ▪ 4* Tie-down Ropes |

SETUP INSTRUCTIONS

1. Remove ice shelter from backpack carrying bag. Remove the tie strap from around the shelter.
2. Lay the ice shelter flat on the ground and be sure there is no material twisted or overlapping the ends of any poles. SEE FIGURE 1.

NOTE: In windy conditions and before pulling outward on the roof or walls to pop open the shelter, securely anchor at all corners with provided ice anchors. See step 6 for instructions. This will prevent shelter from blowing away when setting up in windy conditions.


3. Grasp the webbing loop sewn onto the eyelet located in the center of the roof and pull outward until the roof section pops open. SEE FIGURE 2.

4. Grasp the webbing loop sewn onto the eyelet located in the center of one of the walls and pull outward so that the wall pops open. SEE FIGURE 3.

5. Proceed by walking around entire shelter and pulling on each wall webbing loop to pop out each wall until all sides are popped out. SEE FIGURE 4.

6. Your shelter should be standing up completely. You may now proceed by anchoring the shelter to the ice using the provided ice anchors and rope. SEE FIGURE 5. Screw ice anchors through the grommets located in each corner completely. Use the provided ropes and tie one end to the hub eyelet on each wall, and the other end to an anchor that is already screwed completely into the ice, with proper tension.

NOTE: The ice fishing shelter roof section is designed with two skylights, including clear, cold-weather PVC windows and blackout covers to provide various lighting options. The blackout cover can be opened with a zipper to ensure good lighting conditions; the clear PVC window can be opened with Velcro inside the ice fishing shelter, and the blackout cover can be closed with a zipper inside. SEE FIGURE 6.



TAKE DOWN INSTRUCTIONS

1. Remove all ropes and ice anchors and store them in the provided pouch.

NOTE: Zip all doors shut. Do not leave them open. Close all windows and vents.

In windy conditions, remove ice anchors after collapsing the roof and walls inward.

2. Using your hand, push the center hub in on roof and walls until they collapse inward. The shelter will fall to the ice on its own. SEE FIGURES 7 & 8.

3. The shelter will be back in its flat stage just as it was when it was unfolded out of the backpack bag.

Gather all corners of the shelter and fold together. SEE FIGURE 9.

Do not force the shelter when folding. Watch for entanglement of poles.

4. Take provided tie strap and wrap around folded shelter to allow for easier insertion into backpack.

Place folded shelter back into the backpack carrying bag with the hubs towards the bottom end of bag always. Place the pouch with the ice anchors and rope into backpack as well.

