

ASSEMBLY & INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the wall lamp and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

1. Thread the ROD onto the NIPPLE till tight. Position the Mounting plate(pre-assembled) on the wall at desired location and mark the place for plastic anchors to be installed.
2. Drill pilot holes on the marked spots and insert plastic anchors, thread the wood screws through the MOUNTING PLATE into the plastic anchor by screwdriver.
3. Place the BACK PLATE of the fixture over the MOUNTING PLATE and secure it by threading the BALL FINIALS onto the mounting screws till tight.
4. Screw light bulb into the lamp socket and make sure it does not exceed the maximum wattage specified on the fixture's wattage rating label, **MAXIMUM 40W**. Place the SHADE over the HARP, secure with FINIAL.
5. Plug the power cord into an outlet and turn on at switch.

