



INSTRUCTION MANUAL

EAGLE PEAK Fold Outdoor Privacy Screen with Raised Garden Beds



Thank you for choosing Eagle Peak !



Please read and save the instruction manual before attempting to use your screen.

Global Shade Corporation offers a limited warranty that this product is free from defects in materials and workmanship for a period of one (1) year from the original date of purchase. At its discretion, Global Shade Corporation may provide replacement parts for defective parts to original purchaser after its own review and examination. Original receipt or proof of purchase as well as proof of defect is required.

Global Shade Corporation will not be responsible for shipping costs incurred outside the continental USA. Warranty is valid for the original purchaser for 1 year from the date of purchase and is not transferable. This warranty does not cover any inspection costs.

This Limited Warranty does not cover:







- Labor for replacement of any defective item(s);
- Incidental or consequential damages;
- Cosmetic defects which do not affect performance or integrity;
- Vandalism; improper use or improper installation; acts of nature, including but not limited to wind, storms, hail, floods, excessive water exposure;

Global Shade Corporation does not warrant against and under no circumstances shall Global Shade Corporation be liable or responsible for any personal loss, injury, or direct or indirect incidental or consequential damages resulting from the use of this product.

All replacement products or parts will assume the remaining warranty of the original product. Please email service@eaglepeak.com for customer service.

For warranty service, repair parts, or product questions please email: service@eaglepeak.com.

Part List


No.	Description	Qty.	Sketch
AA	Upper Screen	1	
BB	Lower Screen	1	
CC	Front and Rear Panels of Raised Bed	4	
DD	Side Panel of Raised Bed	4	
EE	Bottom Board of Raised Bed	2	
FF	Grow Bag	2	

ATTENTION:


1. Please check the part list carefully and make sure you have received all the parts.
2. If there is any missing, please let us know the part you need.
3. If there is any damage, please send clear photos to us, we will check and offer you the best solution soon.

Package Includes

Hardware

No.	Description	Qty.	Sketch
a	Bolt (M8x30mm)	12	
b	Bolt (M8x55mm)	8	
c	Washer (M8)	20	
d	Allen wrench	1	
e	Wooden tenons (M8x30mm)	24	
f	Screw (M4x40mm)	28	
g	Screw (M4x20mm)	32	
h	Caster	4	
i	Caster with Brake	4	

Needed for assembly: (The following tools are not included)




Drill



Tape Measure




Goggle




Two people


Step 1




Step 2




Step 3



Step 4




Step 5




Step 6

ATTENTION:


When connect the raised beds with the screen, make sure the casters with the brakes are on the same side.



Step 7



Step 8



The screen can be moved by sliding left and right when the brake is released.

ATTENTION:

When the screen needs to stand for a long time, keep the brakes of the caster in the locking position.

