


ASSEMBLY INSTRUCTIONS


GZPFK-V1

FTLFTS-6009




Notice:

1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly, Fully tighten screws only once all pieces
3. If you encounter any problems during installation, please contact our customer service




FTLFTS-6009


1




2




3




4




5




6




7




8




9




10




11




12




13


















14







FTLFTS-6009

15 	16  x 2	17 
18  x 2	19  x 2	21  1.2M、APP
20 		



A M6x42  20 PCS	B Ø15x12  20 PCS	C M5x40  24 PCS	D M3.5x14  22 PCS	E Ø8x40  8 PCS	F M6x30  8 PCS	G M4x96  2 PCS	H M4x18  4 PCS
I Ø5  4 PCS	J  2 SET	K  4 PCS	L  2 SETS	M  4 PCS	4#  1 PCS	 1 PCS	


Cam Lock Fastening System

This Cam Lock Fastening System will be used throughout the assembly process



FTLFTS-6009







FTLFTS-6009

1

C M5x40




4 PCS








A	M6x42
---	-------




4 PCS



FTLFTS-6009

3



B Ø15x12




4 PCS

D M3.5x14




4 PCS

E Ø8x40






4 PCS

J





2 PCS







FTLFTS-6009



FTLFTS-6009

6

A M6x42	B Ø15x12	C M5x40
		
8 PCS	8 PCS	4 PCS



FTLFTS-6009

7

A M6x42



4 PCS

B Ø15x12










4 PCS

D M3.5x14



8 PCS





FTLFTS-6009

8

Diagram illustrating the assembly of the FTLFTS-6009 unit, showing the installation of the front and back panels (18) onto the side rails (6).

C M5x40

4 PCS

F M6x30

4 PCS


Detailed assembly diagram showing the placement of screws C (M5x40) and screws F (M6x30) to secure the front and back panels (18) onto the side rails (6).

FTLFTS-6009

9

21

A M6x42




4 PCS

D M3.5x14




4 PCS

M





4 PCS


arrow marks must be on the same side before connecting.



Tear off the tape and apply it to the plate, Then press it firmly with your hand





Remove the plastic piece before using the remote .
Read the manual for the remote control .



FTLFTS-6009

10




B Ø15x12



4 PCS

E Ø8x40




4 PCS


F M6x30




4 PCS




11



I Ø5




4 PCS



FTLFTS-6009

12




D M3.5x14




4 PCS

K



4 PCS

J




2 PCS

H M4x18




4 PCS

G M4x96



2 PCS










FTLFTS-6009

13





Attention: For safety and stability, we suggest you have to secure the anti-tip accessories to the wall to prevent tipping, injury, and property damage.

WALL



WALL



D M3.5x14



2 PCS