

Fig.3

Replacing LED module (Fig. 3)

The LED module can be replaced by a qualified electrician without cutting of wire and without damage to any decorative element to which the fixture is attached. See installation steps for more details (Fig.3.)

- a. Shut off power. Remove the four mounting screws (DD) from the side of the canopy (A).
- b. Disconnect the wires by removing wire nuts. Take the whole fixture down to the working table.
- c. Disconnect the wires of the driver by removing wire nuts. Press the wire restraint (F) on the canopy (A) to release the wire (E) out from the canopy (A).
- d. Remove the screws (GG) from the fixture body (D).
- e. Remove the four screws (II) from the four barrels (HH)
- f. Remove the four screws (JJ) from the four barrels (KK)
- g. Remove top plate (G) with the LED board and wire (E).
- h. Reverse steps a-g for installing the new LED module.

Note: The LED module should be provided by a specified supplier.

