

Adventure Starts Here.

37" X 71" RECTANGLE DINING TABLE

SEAHAWK
DESIGNS


EST. 2005

! NOTICE

- Do not overtighten hardware.
- Do not exceed the weight capacity of this item.
- Only use this item for what it is intended for, improper use will void any warranty.
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are firmly secured every 90 days.
- Keep this furniture clear of all uncontrolled open flames or flammable/combustible materials.
Exposure to fire, high heat, or embers will permanently damage the material.
- To avoid stripping and cracking of the material, DO NOT use power tools for assembly.
- Always prioritize caution and safety throughout the assembly process.

TOOLS REQUIRED

ALLEN WRENCH
(PROVIDED)



WRENCH
(PROVIDED)



**CHECK PARTS
& HARDWARE
FIRST***



**SUGGESTED
2 PERSON
ASSEMBLY**



**ESTIMATED
ASSEMBLY
TIME: 20 MIN**

*For missing parts or hardware, please email cs@seahawkdesigns.com.

1

SCREW
M6 x 70mm



16 PCS

2


SCREW
M6 x 80mm



16 PCS

3

BOLT
M6 x 55mm



16 PCS

4

M6-NUT



16 PCS

5

M6-WASHER



16 PCS

6

SCREW HOLE PLUG




16 PCS

PARTS

REF#: OP8049

A


TABLE TOP



1 PC

B

LEG



8 PCS

C


RAIL



4 PCS

D


FOOT BASE



4 PCS

PRODUCT ASSEMBLY - OVERALL VIEW


Please refer back to this image during the assembly process for part placement.



1

Step 1: Attach the Rail to Legs



- Attach **Part C (Rail)** to **2 - Part B (Leg)** using **4 - M6 Screw (#1)** (see image below).
- Repeat the same step to assemble the other 3 - sets of legs.
- Do not fully tighten the bolts yet. Tighten them to approximately 70% to allow for adjustments during final assembly.



2

Step 2: Attach the Foot Base to the Legs


- Attach **2 - Part D (Foot Base)** onto **2 - Assembled Legs (Part B, Part C and Part B)** using **8 - M6 Screw(#2)** (see image below).
- Repeat the same step to assemble another set of legs.



3

Step 3: Attach the Assembled Legs to the Table Top


- Place **Part A (Table Top)** upside down on a flat, stable surface.
- Attach the **Assembled Legs (4 - Part B, 2 - Part C, 2 - Part D)** to **Part A (Table Top)** using **8 - sets of M6 Bolt (#3), M6 Washer (#5), and M6 Nut (#4)** (see image below).



4

Step 4: Final Tightening and Stability Check


- Repeat the previous step (Step 3) to assemble the other set of **Legs (4 - Part B, 2 - Part C, 2 - Part D)** to **Part A (Table Top)** using **8 - sets of M6 Bolt (#3), M6 Washer (#5), and M6 Nut (#4)** (see image below).



5

Step 5: Final Tightening and Stability Check

- Tighten all previously installed screws, bolts, and nuts. Check every connection to ensure the table is steady and stable.




6

Step 6: Apply the Screw Hole Plugs

- Cover all exposed screw holes using **16 - Screw Hole Plug (#6)**. Insert all plugs into the exposed screw holes. Gently tap each plug into place using a rubber mallet to prevent damage. Ensure each plug is fully seated and flush with the chair surface (see image below).

ATTENTION: Do not use a metal hammer as it will damage the poly lumber.



- **REGULAR CLEAN:** Mix **warm water** and **mild soap**. Use **a soft bristle brush** to gently scrub the surface and remove any dirt or stains.
- **QUICK CLEAN:** Simply wipe the furniture down using a damp cloth.

Tip: Cleaning your furniture regularly helps maintain its aesthetic appeal and extends its lifespan.

Enjoy!

Join our community and be the first to see what's new!

Follow us on socials:



Quickly register your outdoor furniture purchase to activate your warranty and enjoy peace of mind with guaranteed product protection:



Have questions or need assistance? Reach out to our dedicated team at **(909) 284-1052** or email us at **cs@seahawkdesigns.com**.