

IMPORTANT INFORMATION ABOUT YOUR GARCIMA BURNER

BEFORE USING THE BURNER,
BE SURE TO READ THIS SHEET AS IT COVERS KEY SAFETY TIPS AND INSTRUCTIONS.

GARCIMA'S MANUFACTURER MANUAL IS ALSO INCLUDED AS A SEPARATE INSERT.
YOU MAY CONTACT US WITH QUESTIONS: 718-507-1620 OR CONTACT@PAELLAPANS.COM.

- Propane burners and charcoal BBQ grills are for outdoor use only.
- Keep children and pets away from the burner when it is lit.
- Set burner on a fireproof surface or use an appropriate burner tripod.
- Do not move the burner while in use.
- Do not leave the burner unattended.
- Level the burner with the pan on top before starting to cook.

Before First Use:

- Inspect the burner for any defects.
- Unscrew the brass burner adapter piece on the nozzle that connects to regulator and hose. There should be a black rubber gasket inside the adapter, which is a safety component. Once you confirm it is present, reattach the burner adapter (tightening it hard by hand).
- **If the gasket is missing, do not use the burner and call or email us for a replacement.**

Before Every Use, Check For Gas Leaks Using The "Soapy Water" Test - NEVER SKIP THIS STEP:

- Before connecting the burner to the propane tank, make sure all knobs are off (turned clockwise until they stop).
- To test for leaks, use the soapy water method: Connect the regulator and hose to the burner and propane tank. At the burner nozzle, lightly wrench-tighten the hose, but do not over-tighten.* Fill a spray bottle with water and a good dose of dishwashing liquid. Shake well, and spray all the hose and burner connection points, as well as behind the burner knobs. Open the gas at the propane tank; do not light the burner.
- Look for bubbles at all soapy water points. In the event of bubbles, which indicate a leak, turn off the gas and tighten the connections, apply plumber's tape, and then retest. Do not light the burner if there is a leak. Replace the hose or have the burner serviced by a gas professional.
- **Remember to do the soapy water test before each use.**

To Turn On The Burner:

- Be sure the burner knobs are off, turned all the way clockwise. Then open the propane tank valve.
- First light the inside burner ring: Push in and turn counter-clockwise the knob that controls the inner ring (the knobs on G models turn without pushing in). Using a long handled lighter, light a few of the holes of the ring. The flame will spread around the ring.
- Use the control knob to adjust the strength of the flame.
- Light the middle and outer rings the same way.

To Turn Off The Burner:

- First close off the valve at the propane tank.
- Turn the control knobs off by turning clockwise until they stop.
- Let the burner cool down before storing.

***TO REMOVE REGULATOR HOSE:** Most burner models have a brass adapter on the nozzle that attaches to the regulator hose. If you remove the hose from the burner, be sure this adapter remains on the burner and that the rubber gasket remains inside the adapter. Use 2 wrenches, one on the adapter and the other on the regulator, to gently unscrew.