



If you have any questions, please contact our customer care center. Our contact details are below:

416-792-6088

customerservice@aosom.ca

Imported by Aosom Canada Inc.
7270 Woodbine Avenue, Unit 307, Markham, Ontario Canada L3R 4B9
MADE IN CHINA

IMPORTANT: Save these instructions – *DO NOT DISCARD.*

PARTS INCLUDED:

- 12 Ice anchors
- 6 Tie down straps
- Carry and storage bag

LONG TERM STORAGE

Please make sure your tent is completely dried out after each use and before storing for long periods of time. Store shelter in a cool, dry place away from rodents.

SAFETY AND MAINTENANCE

Please fully understand and follow all safety instructions outlined below. Failure to do so could result in severe injury or death.

- Do not use open flame heaters in your ice shelter, injury or death may result from fire if tent fabric is exposed to open flame.
- Never leave shelter unattended when set up
- Use extra tie downs during excessive winds

- Due to traffic on lakes, ice fishing can be hazardous at night. If you choose to fish at night or in conditions with poor visibility, be sure to take precautions with lights or reflectors. Exterior reflectors must be visible to reduce risk of collisions.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.

This tent is made of flame-resistant fabric. It is not fireproof. The fabric will burn if left in continuous contact with a flame source. Death from asphyxiation may result from use of oxygen depleting heaters. Open all vents for fresh air ventilation.

This tent is made with flame resistant fabric which meets CPAI-84 specifications.



AB1-005/AB1-006


Setup Instructions

1




Step 1: Remove ice shelter from the carrying bag. Remove pouch with anchors and straps. Remove tie strap from around the shelter.

2




Step 2: Lay the ice shelter on the ground and check that there is no material twisted or overlapping the ends of any poles. ****Tip -** Watch for entanglement of poles. DO NOT force shelter when unfolding or folding. Excessive force could cause breakage of poles.

3




Step 3A: Pull outward on the loop on one of the walls. Continue around the entire shelter pulling each loop outward on wall hub until all sides are popped out. ****Tip -** Place your foot on the ground skirt to help hold the shelter in place when popping open the walls




Step 3B: From inside the shelter, push upwards on the roof hub until it pops into place.

4



Step 4A: Position the shelter over fishing hole in ice and secure each loop on inside corners/walls of ice shelter to ice using the provided ice anchors. ****Tip -** Push down while twisting ice anchor until it gets started and then twist the anchor until it holds fast.




Step 4B: Find the side of the shelter that faces into the wind and attach the strap provided. Stretch the strap into the wind and with the remaining anchor secure the strap to the ice. ****Tip -** Shovel snow onto the skirt around the entire fishing shelter.

Take Down Instructions


1

****Tip -** Zip all doors shut. Do not leave them open. Close all windows and vents. Remove all ice and snow from the shelter before take down.




Step 1: Unscrew the ice anchors from the inside corners/walls and remove tie down(s) from the outside wall(s). Place all anchors and straps in the supplied pouch and store in the carrying bag.

2




Step 2: Using your hand, push in center hub on one outside wall until it collapses inward. Continue around the outside of shelter collapsing all remaining walls.

3




Step 3: Using your hand, push in center hub of roof until the roof flattens down onto the sides.

4




Step 4: Once the unit is lying flat, lift each of the corners together and stand the folded unit with all of the hubs facing down.

5



Step 5: Lay the collapsed shelter down and use the strap to secure all sides.

6



Step 6: Place the shelter into the carrying case hubs first. Place the pouch with the ice anchors and tie down straps into the carrying case as well.



Si vous avez la moindre question, veuillez contacter notre centre d'assistance à la clientèle. Nos coordonnées sont les suivantes:

☎ 416-792-6088

✉ customerservice@aosom.ca

Importé par Aosom Canada Inc.
7270 Woodbine Avenue, unité 307, Markham,
Ontario Canada L3R 4B9
Fabriqué en Chine

IMPORTANT: Conservez ces instructions - **NE PAS LES JETER.**

PIÈCES INCLUSES:

- 12 ancrs à glace
- 6 Sangles de fixation
- Sac de transport et de stockage

STOCKAGE À LONGUE PÉRIODE

Assurez-vous que votre auberge de poisson est complètement sèche après chaque utilisation et avant de la stocker pendant de longues périodes.

SÉCURITÉ ET ENTRETIEN

Veuillez bien comprendre et suivre toutes les instructions de sécurité décrites ci-dessous, faute de quoi des blessures graves, voire mortelles pourraient en résulter.

- Do N'utilisez pas de chauffage à flamme nue dans votre abri de glace. Un incendie pourrait provoquer une mort si le tissu de l'abri est exposé à une flamme nue.
- Ne laissez jamais l'abri sans surveillance lors de la mise en place
- Utilisez des attaches supplémentaires par vent excessif

- En raison de la circulation sur les lacs, la pêche sur glace peut être dangereuse la nuit. Si vous choisissez de pêcher la nuit ou dans des conditions de visibilité réduite, veuillez prendre des précautions avec des lumières ou des réflecteurs.

Les réflecteurs extérieurs doivent être visibles pour réduire les risques de collision.

AVERTISSEMENT: TENEZ TOUTES LES SOURCES DE FLAMME ET DE CHALEUR À L'ÉCART DE CE TISSU.

Cette tente est en tissu résistant aux flammes. Ce n'est pas ignifuge. Le tissu brûlera s'il reste en contact permanent avec une source de flamme. L'asphyxie peut entraîner la mort par l'utilisation d'appareils de chauffage appauvrissant en oxygène. Ouvrez tous les orifices de ventilation pour la ventilation d'air frais. Cette tente est fabriquée avec un tissu ignifuge conforme aux spécifications CPAI-84.




Instructions d'Installation

1




Étape 1:
Retirez l'abri de glace du sac de transport. Enlevez le sac avec les ancrs et les sangles. Retirez la sangle de cravate autour de

2




Étape 2:
Posez l'abri de glace sur le sol et vérifiez qu'il n'y a pas de matériau tordu ou qui chevauche les extrémités des poteaux.
**** Conseil -** Surveillez l'enchevêtrement des pôles. NE PAS forcer l'abri lors du déploiement ou du pliage. Une force excessive pourrait causer la rupture des poteaux.




Étape 1:
Dévissez les ancrages à glace des coins / murs intérieurs ; et retirez les sangles d'arrimage des murs extérieurs. Placez toutes les ancrs et les sangles dans la pochette fournie, et rangez-les dans le sac de

2




Étape 2:
À l'aide de votre main, poussez le moyeu central sur un mur extérieur jusqu'à ce qu'il s'effondre vers l'intérieur. Continuez effondrer tous les murs restants autour de l'abri.

3




Étape 3A:
Tirez vers l'extérieur sur la boucle sur l'un des murs. Continuez autour de l'abri tirer chaque boucle du moyeu mural vers l'extérieur jusqu'à ce que tous les côtés s'éclatent.
**** Conseil -** Placez votre pied sur la jupe au sol pour aider à maintenir l'abri en place lorsque vous ouvrez les murs




Étape 3B:
Depuis l'intérieur de l'abri, poussez le moyeu du toit vers le haut jusqu'à ce qu'il se mette en place.

3




Étape 3:
Poussez le moyeu du toit avec la main jusqu'à ce que le toit s'aplatisse sur les côtés.

4




Étape 4:
Une fois l'unité à plat, soulevez chacun des coins, et placez l'unité pliée avec tous les moyeux dirigés vers le bas.

4



Étape 4A:
Placez l'abri au-dessus du trou de pêche dans la glace et fixez chaque boucle sur les coins / murs intérieurs de l'abri à la glace à l'aide des ancrs à glace fournis.
**** Conseil -** Poussez vers le bas tout en faisant pivoter l'ancre à glace jusqu'à ce qu'elle soit démarrée puis tournez l'ancre jusqu'à ce qu'elle tienne bien.



Étape 4B:
Identifiez le côté de l'abri face au vent et attachez la sangle fournie. Étirez la sangle dans le vent et fixez-la à la glace avec l'ancre restante.
**** Conseil -** Pelle la neige sur la jupe autour de tout l'abri de pêche.

5



Étape 5:
Mettez l'abri qui s'est effondré et fixez tous les côtés avec une sangle.

6



Étape 6:
Placez l'abri dans les moyeux du sac de transport en premier. Placez la pochette avec les ancrs à glace, et fixez également des sangles dans le sac de transport.