



FOR REPLACEMENT PARTS OR HELP WITH ASSEMBLY PLEASE CONTACT US

PLEASE ENSURE TO HAVE THE MODEL # FROM THE PACKAGING OR INSTRUCTION BOOKLET

TO RETURN THE PRODUCT: PLEASE CONTACT THE RETAILER WHERE THE ITEM WAS PURCHASED FROM

ENTER TO WIN

Upload an image of our furniture in your home with a short review to our facebook page for a chance to

> Win up to \$3000 of us !!!

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.


May require 2 people for ease of assembly.


CARE and MAINTENANCE


To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth. Dust with soft dry cloth.

Do not use ammonia-based cleaning products, as they will damage the finish. Do not leave liquids or damp cloths on this furniture.


To avoid dulling of the finish, do not place furniture in direct sunlight. Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.











COMPONENTS-KEY DIAGRAM














- 1. Attach three Cam Lock Pins (5) to each Sides (A).
- Align Cam Lock Pins with pre-drilled holes and attach Middle Shelf (N).
 Insert six Cam Lock (5) into pre-drilled holes on Middle Shelf (N).
- 4. Use flathead screwdriver to secure Cam Locks.




- 1. Attach Bottom C to Sides A and Small Divides Using twelve Allen Key Screws (1) (three Screws on each Side and Small Divider).
- 2. Use Allen Key (3) to tighten Screws. Do not over-tighten.




- 1. Attach Legs (G) to Bottom (C).
- 2. Use xis Allen Key Screws 1 to secure part C and G (three Screws on each Leg)
- 3. Use eight sets Bolts and Washers (2) to secure part (C) and (G) (four sets on each Leg).
 4. Use Allen Key (3) to tighten Bolts and Screws. Do not over-tighten.




- 1. Insert two Wood Dowels B into pre-drilled holes on each Side A.
- 2. Use rubber mallet to tap Wood Dowels (8) into bottom of holes securely. 1/2 length of Dowels should be exposed.
- 3. Attach Top B to Sides A and Divider D using nine Allen Key Screws 1(three screws on each Side and Divider).
- 4. Use Allen Key(3) to tighten Screws. Do not over-tighten.





- 1. Use four Shelf Supports 6 for each Cabinet Shelf F in desired location.
- 2. Two Shelf Supports (6) may be used on back top of each Cabinet Shelf (F) as a tipping restraint.
- 3. Insert assembly drawers into glides on assembly medium storage.




1. Slide the wheels on bottom of each door to the slots on Middle Shelf \mathbb{N} .

2. Pull down the pins on top of each door then place the door to be parallel with the medium storage side post. Afterward release the pins. The pins will be inserted into the slots underneath of Top (B).

3. To adjust the height of wheels up or down, use the Small Allen Key (7) to rotate the bolts on the wheels (Rotating clockwise will adjust the wheels higher, rotating counter clockwise will adjust the wheels lower).

NOTE: Injuries and damage can occur from furniture tip-over. It is important to use the safety bracket included. If the tipping restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.



WARRANTY

Thank you for purchasing product us. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.) please contact us at our toll free service

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.