

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in boxes for hardware packs and legs.

Dining Chair





Parts List

Label	Picture	Description	QTY
A		Chair	1
B		Front Leg	2
C		Back Leg	2

Hardware

Label	Picture	Description	QTY
①		Bolt (M8X50mm)	9
②		Spring Washer	9
③		Flat Washer	9
④		Allen Wrench	1

Assembly Preparation

Before Beginning Assembly:	 X9  X9  X9 			
	 A  X2 B  X2 C			



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps


Overview



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Friendly reminder: Tighten all the screws after all holes are installed.

Step 1




Open the carton, and place all parts on a clean, non-marring surface.

Take out Chair(A)

Reveal the bottom, unzip and expose the frame.

Step 2




Take out Back Leg (C)

Insert Back Leg (C) into the hole as shown (pay attention to the insertion direction)

Use Bolt(①), Spring Washer(②) and Flat Washer(③) with Allen Wrench(④) to tighten it.

Step 3




Take out Front Leg (B)

Insert Front Leg (B) into the hole as shown (pay attention to the insertion direction)

Use Bolt(①), Spring Washer(②) and Flat Washer(③) with Allen Wrench(④) to tighten it.

Zip up the bottom after checking all four legs are assembled.

Step 4



Place the Chair right side up and tested for stability.

Your Chair is ready for use.

This CHAIR can only be used on a flat, level surface.