

# TULIPBAB-LQ




Ax1		Fx1	M6x45MM
Bx1		Gx4	M6x55MM
Cx1		Hx5	
Dx1		Ix1	
Ex2	M6x35MM	Jx4	

## SPARE (Ersatzteile)

Ex1	M6x35MM	Hx1	
Gx1	M6x55MM	Jx1	


### STEP 1



A		1
B		1
E	M6x35MM	2
I		1




### STEP 3



G	M6x55MM	4
H		4
I		1




### STEP 2



C		1
D		1
F	M6x45MM	1
H		1
I		1



### STEP 4



J		4
---	--	---

