

Instruction Manual

Glass Table Lamp

Questions?

E-mail our customer service department


IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electrical shock and fire, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter this safety feature.

This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids. Never cover the lamp with any object including cloth or paper as this is a fire hazard. Do not handle the bulb immediately after the light is turned off as it will be hot. This is not a toy.

ASSEMBLY INSTRUCTIONS:

1. Carefully remove all parts from the carton.
2. Gently pull the cord from the bottom of the lamp until the Socket Assembly (B) is close enough to screw into Base (A).
3. Screw Socket Assembly (B) counter clockwise until tight against Base (A).
4. Place Harp (D) into Saddle (C).
5. Remove the plastic from shade (E) and place onto Harp (D) and secure in place with Finial (F).
6. Install light bulb. Only use bulb of specified type and maximum rated wattage or less. Turn the lamp ON/OFF using the rotary switch located on the socket.



Requires 1 x 150W 3-way Type A Medium Base Bulb
(not included)

CLEANING & MAINTENANCE:

1. Unplug the fixture before cleaning.
2. Use a clean, dry, soft, lint-free cloth.
3. Do not use water or other chemical cleaning agents.

LIMITED WARRANTY

PRINTED IN CHINA