


Sidetable


CTG053 | 40CM 3 Drawers

Assembly Instructions




Assembly Diagram

CTG053 | 40CM 3 Drawers



Parts List


CTG053 | 40CM 3 Drawers



1 Left side panel

510 × 400 × 17MM


Quantity: 1



2 Right side panel

510 × 400 × 17MM


Quantity: 1



3 Top panel

366 × 374 × 17MM

Quantity: 1




4 Middle crossbar

366 × 55 × 17MM

Quantity: 1

Parts List


CTG053 | 40CM 3 Drawers



5 Upper / lower crossbar

366 × 55 × 17MM


Quantity: 2



6 Base panel

366 × 356 × 17MM


Quantity: 1



7 Back panel

473 × 376 × 5MM

Quantity: 1




8 Lower drawer front

360 × 173 × 32MM

Quantity: 1

Parts List


CTG053 | 40CM 3 Drawers



9 Lower drawer back

317 × 120 × 12MM


Quantity: 1



10 Lower drawer left side

300 × 120 × 12MM


Quantity: 1



11 Lower drawer right side

300 × 120 × 12MM

Quantity: 1




12 Drawer bottom

327 × 286 × 5MM

Quantity: 3

Parts List


CTG053 | 40CM 3 Drawers



13 Middle drawer front

360 × 96 × 32MM


Quantity: 1



14 Upper drawer front

360 × 96 × 29MM


Quantity: 1



15 Upper / middle drawer back

317 × 60 × 12MM

Quantity: 2




16 Upper / middle drawer left side

300 × 60 × 12MM

Quantity: 2

Parts List


CTG053 | 40CM 3 Drawers



17 Upper / middle drawer right side

300 × 60 × 12MM


Quantity: 2



18 Pull-out shelf back rail

360 × 60 × 17MM

Quantity: 1




19 Pull-out shelf

360 × 319 × 25MM

Quantity: 1

Hardware & Tools


CTG053 | 40CM 3 Drawers



A Cam locks

Ø15 × 9MM


Quantity: 26 + 2



B Cam bolts

L=35MM


Quantity: 26 + 2



C Cover stickers

20MM

Quantity: 10 + 2




D Wood dowels

8 × 30MM

Quantity: 8 + 1

Hardware & Tools


CTG053 | 40CM 3 Drawers



E Connector screws

#7 × 35MM

Quantity: 2 + 1




F Hex key

M4 × 100MM

Quantity: 1


Reusable tool



G Threaded stops

M6 × 12MM

Quantity: 2




H Screws

#8 × 25MM

Quantity: 24 + 2

Hardware & Tools

CTG053 | 40CM 3 Drawers




I Phillips screwdriver

M6 × 128MM

Quantity: 1

Reusable tool




J Casters with brakes

M6 × 12MM × 1 inch

Quantity: 2

Total height: 38MM



K Casters without brakes

M6 × 12MM × 1 inch

Quantity: 2



L Open-end wrench


#12MM

Quantity: 1

Reusable tool

Hardware & Tools

CTG053 | 40CM 3 Drawers




M Three-section ball-bearing slides

L=250 × 35MM; 10 inch

Quantity: 3 sets (6 pieces)

Wall thickness: 1MM



N Screws

#3.5 × 12MM

Quantity: 36 + 3

Safety Warnings

CTG053 | 40CM 3 Drawers

Place the unit on a level surface, or level it with the included

hardware when applicable.

Do not sit or stand on the product. Do not allow children to climb, sit or stand on it.

For safety, the unit must be secured to the wall.

Do not use the unit without installing the tip restraint.

The unit can tip over and cause severe injury or death.

Do not exceed the recommended weight limits.


Distribute weight evenly on each level. Keep heavier loads at the bottom.

Before cutting, drilling or hammering into a wall or floor, check for electrical wiring, plumbing and gas lines. Cutting into them can cause serious injury.


Cam Lock Assembly

CTG053 | 40CM 3 Drawers


Illustration key: A = cam bolt; B = cam lock.




1. Screw the cam bolt into the panel.




2. Insert the cam lock with its arrow pointing toward the panel edge.



3. Align the cam bolt and cam lock.
Insert fully into the cross-bored hole.



4. Turn the cam lock clockwise
190°–230° to lock the panels.



5. Check that the panels fit tightly
and the connection is rigid.

Dowel & Connector Fit





CTG053 | 40CM 3 Drawers

Insert Wood Dowels D at least halfway into their holes.

If necessary, tap gently with a rubber mallet.

Follow the insertion depths shown below.

Illustration key: A = wood dowel; C = connector.



Step 1

CTG053 | 40CM 3 Drawers

Separate each Slide M into its main rail and removable inner rail.

Press the black plastic release lever in the direction shown.




Set all removable inner rails aside for Step 2.

Attach the main rails to Panels 1 and 2 using Screws N.

Extend the inner sections of the main rails to access the screw holes.

Face the release-lever ends of the main rails toward the front.

Hardware: M × 3 sets N × 18 Tool: I (reuse)



Step 2


CTG053 | 40CM 3 Drawers

Attach the removable inner rails from Step 1 to Parts 10, 11, 16 and 17.

The grooves on Parts 10 and 16 face the front end of each slide.

The grooves on Parts 11 and 17 face the rear end of each slide.

Hardware: N × 18 M: inner rails from Step 1; I: reuse




Step 3

CTG053 | 40CM 3 Drawers

Install Cam Bolts B in Panels 1, 2, 3 and 6 using Tool I.

Hardware: B × 26 Tool: I (reuse)







Step 4

CTG053 | 40CM 3 Drawers

Attach one Crossbar 5 to Top Panel 3 and the other to Base Panel 6.

Use Cam Locks A and Tool I, as shown.

Hardware: A × 2 Tool: I (reuse)




Step 5

CTG053 | 40CM 3 Drawers

Insert Dowels D into Right Side Panel 2 at the indicated positions.

Hardware: D × 4



Step 6




CTG053 | 40CM 3 Drawers

Join the assemblies from Step 4 to Right Side Panel 2.

Attach Middle Crossbar 4 to Panel 2 in the position shown.

Use Cam Locks A and Tool I.


Hardware: A × 12 Tool: I (reuse)



Step 7

CTG053 | 40CM 3 Drawers

Slide Back Panel 7 into the grooves of the assembly from Step 6.
Keep the hole in Back Panel 7 facing upward, as shown.




Step 8

CTG053 | 40CM 3 Drawers

Insert Dowels D at the indicated positions in the assembly.

Hardware: D × 4






Step 9

CTG053 | 40CM 3 Drawers

Attach Left Side Panel 1 to the assembly from Step 8.

Use Cam Locks A and Tool I.

Hardware: A × 12 Tool: I (reuse)





Step 10

CTG053 | 40CM 3 Drawers

Attach Back Rail 18 to Pull-out Shelf 19 using Screws E and Hex Key F.

Hardware: E × 2 Tool: F (reuse)






Step 11

CTG053 | 40CM 3 Drawers

Slide the shelf assembly from Step 10 along the tracks in Panels 1 and 2.

Turn Stops G clockwise into the indicated holes behind Shelf 19.

Hardware: G × 2



Step 12




CTG053 | 40CM 3 Drawers

Install Casters J and K in Base Panel 6 using Wrench L, as shown.

The casters may be omitted depending on use.

Operate the brake switches as shown to control movement.

Hardware: J × 2 K × 2 Tool: L (reuse)





Step 13

CTG053 | 40CM 3 Drawers

Apply Cover Stickers C to the indicated holes on the back of the cabinet.

Hardware: C × 10



Step 14


CTG053 | 40CM 3 Drawers

Attach Sides 10 and 11 to Lower Drawer Front 8.

Attach Sides 16 and 17 to Upper Front 14 and Middle Front 13.

Use Screws H and Tool I to make three drawers.


Hardware for all three drawers: H × 12 Tool: I (reuse)



Step 15

CTG053 | 40CM 3 Drawers

Slide one Bottom Panel 12 into the grooves of each drawer.




Step 16

CTG053 | 40CM 3 Drawers

Attach Back Panel 9 to the lower drawer and one Back Panel 15 to each upper and middle drawer, using Screws H and Tool I.



Hardware for all three drawers: H × 12 Tool: I (reuse)



Step 17

CTG053 | 40CM 3 Drawers

Pull the inner sections of the main slides fully out to their stops.
The slides may be slightly greasy. Align the drawer rails with them,
then push each drawer inward gradually in several stages.



Step 18

CTG053 | 40CM 3 Drawers

Assembly complete.

