

Coffee Store Playset

(WG388)



98.1WG388.150


Assembly Instruction

Please follow this instruction to avoid assembly errors.

















For customer service, please contact *E-mail:shop@robud.com*

WARNING:

















- CHOKING HAZARD-Small parts.Not suitable for children under 3 years.
- Toys intended to be assembled by an adult. Children should use the product under adult's guidance.
- After opening the package,please keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation.
- Please keep the product away from fire, substances flammable and humid environments to prevent damage.
- Please keep the product away from water, and don't put liquid in the toy sets.
- Please clean the product with dry soft cloth, don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- The instruction must be retained since it contains important information.











Product Parts

1 	2 	3 	4 
x1	x1	x1	x1
5 	6 	7 	8 
x1	x1	x1	x1
9 	10 	11 	12 
x1	x1	x1	x1
13 	14 	15 	16 
x1	x1	x1	x1








Product Parts

 <p>17</p>	 <p>18</p>	 <p>19</p>	 <p>20</p>
x1	x1	x1	x1
 <p>21</p>	 <p>22</p>	 <p>23</p>	 <p>24</p>
x1	x1	x1	x1
 <p>25</p>	 <p>26</p>	 <p>27</p>	 <p>28</p>
x1	x1	x1	x1
 <p>29</p>	 <p>30</p>	 <p>31</p>	 <p>32</p>
x1	x1	x1	x1

















Product Parts

<p>33</p> 	<p>34</p> 	<p>35</p> 	<p>36</p> 
<p>x1</p>	<p>x1</p>	<p>x1</p>	<p>x1</p>
<p>37</p> 	<p>38</p> 	<p>39</p> 	<p>40</p> 
<p>x2</p>	<p>x2</p>	<p>x1</p>	<p>x1</p>










Hardware

<p>41</p>  <p>4x25</p>	<p>42</p>  <p>4x14</p>	<p>43</p>  <p>4x10</p>   <p>a b</p>	<p>44</p>  <p>3x10</p> 
<p>x73</p>	<p>x4</p>	<p>x4</p> <p>x2</p>	<p>x6</p> <p>x3</p>

Accessories


<p>45</p>  <p>3x8</p>	<p>46</p>  <p>4x20</p>		
<p>x6</p>	<p>x3</p>	<p>x4</p>	<p>x2</p>
			
<p>x2</p>	<p>x1</p>	<p>x1</p>	<p>x1</p>
			
<p>x1</p>	<p>x6</p>	<p>x1</p>	<p>x1</p>
			
<p>x1</p>	<p>x1</p>	<p>x1</p>	<p>x1</p>

Accessories


			
x1	x1	x1	x1
			
x1	x1	x1	x1
			
x1			

Assembly Instruction


1




2



3




4




Assembly Instruction


5




6



7




8




Assembly Instruction

9




- 43 4x10 x2pcs
- 45 3x8 x2pcs
- 46 4x20 x2pcs

10




- 41 4x25 x2pcs

11




12




Assembly Instruction

13



TIPS:
Please assemble the buttons
as shown sequence.


14



Assembly Instruction


15

41 4x25
x6pcs




16


41 4x25
x2pcs




Assembly Instruction


17

41  4x25
x6pcs




18


41  4x25
x4pcs




Assembly Instruction


19

41  4x25
x6pcs




20


41  4x25
x2pcs




Assembly Instruction

21


41  4x25
x6pcs



22


41  4x25
x4pcs


TIPS:
Please assemble Board 28 firstly,
then proceed to other steps.




Assembly Instruction


23

41  4x25
x6pcs




24

41  4x25
x4pcs





Assembly Instruction

25




26


41  4x25
x2pcs




Assembly Instruction


27

41  4x25
x2pcs




28

41  4x25
x2pcs



Assembly Instruction


29




41 4x25
x14pcs

Assembly Instruction

30





robud

www.robud.com