La Plus Belle

# ASSEMBLING & INSTALLATION INSTRUCTIONS

The drawing shown may not exactly match the product enclosed.
However, the installation instructions do apply to this product.

***WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

***ATTENTION! COUPER LE COURANT AU FUSIBLE OU UN DISJONCTEUR.

## INSTALLING THE FIXTURE (Fig.1)

1. Shut off the power at the circuit breaker box. Remove old fixture and all hardware from Junction Box. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.
2. Before installation, press the **Cord Adjustment Nut** to set the exposed wire length as desired.
3. Attach the **Mounting Plate** to the junction box using two **Mounting Screws** as shown. The side of the mounting plate marked “GND” must face out. The junction box is not included.
4. Follow wiring instructions carefully.(see fig.2)
5. Install **Fixture Ceiling Canopy** on the **Mounting Plate** and secure it with **Mounting Nuts**.

## CONNECTING THE WIRES (Fig.2)

1. Connect the electrical wires as follows. Connect the Black wire from the fixture to the black house (hot) Wire. Connect the white wire from the fixture to the white (neutral) house wire. Make sure all wire nuts are secured. You may wrap the connections with electrical tape. If your outlet box has a ground wires (green or bare copper) connect fixture’s ground wire to it. Otherwise attach the bare copper fixture wire to the **Green ground screw** on the **mounting plate**.
2. Tuck the wire connections neatly into the wall junction box.

Your installation is now complete. Return power to the junction box and test the fixture.

FIG.1






FIG.2




MADE IN CHINA

LA2697-LH