


























ASSEMBLY INSTRUCTION
This installation manual is the correct version

Note: Distinguishing between the numbers 6 and 9 is different, with the number 9 underlined; Please tighten all screws by 60% first, and then tighten them by 100% after installation is complete.




1.x2 	2.x2 	3.x2 	4.x2 	5.x2 
6.x1 	7.x2 	8.x1 	9.x1 	10.x10 
11.x1 	12.x1 	13.x2 	14.x10 	15.x1 
A.x8pcs  M8x55mm	B.x4pcs  M6x55mm	C.x27pcs  M6x35mm	D.x4pcs  M8x16mm	E.x4pcs  M8
F.x12pcs  M8x16mm	G.x31pcs  M6x16mm	H.x1pcs  M6	I.x4pcs  M8	J.x1pcs  4#
K.x1pcs  5#	L.x1pcs  M8	M.x8pcs  20x40mm	O.x40pcs 	P.x2pcs 
Q.x4 	R.x1 	V.x2 		



1
F
D
K
3
F
D
2
4
x2
2
G
C
K
1
5
M
G
C
K
x2
x2
3
A
E
L
x4
K
A
F
7
7


4
G
B
K
x4
6
5
P
8
P
G
C
K
x2
8


6




7




8




9



⑩



⑪



⑫

