

INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF; EITHER THE FUSE IS REMOVED OR THE CIRCUIT BREAKER IS SHUT OFF.

GENERAL

You don't need special tools to install this fixture. Be sure to follow the steps in the order given. Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling, which contains a radiant type heating system. Read instructions carefully. If you are unclear as to how to proceed, consult a qualified electrician.

NOTE: Proper wiring is essential for the safe operation of this fixture.

FIXTURE ASSEMBLY

Carefully remove the fixture from the carton and check that all parts are included as shown in figure. Be careful not to misplace any of the screws or parts, which are needed to install this fixture.

INSTALLATION

Step 1: Secure the mounting bracket (A) to the outlet box(not included) by using two outlet box screws(B).

Step 2: Based on the desired length of the stems (J, I, H), thread the fixture wire and fixture ground wire through the stems and the canopy (F). then screw them together.

Step 3: Pull out the source wires from the outlet box(not included).
Make wire connections with wire connectors(C) as follows:
--Use the wire connector(C) to connect the white fixture wire to the white (neutral) supply wire from the outlet box (not included).
--Use the wire connector(C) to connect the black fixture wire to the black (live) supply wire from the outlet box (not included).
--Wrap the ground wire from the fixture around the ground screw (D) on the mounting bracket (A). Then use the wire connector (C) to connect the ground wire from the fixture to the ground wire from the outlet box (not included). Carefully put the wires back into the outlet box (not included).

Step 4: Secure the canopy (F) to the mounting bracket (A) with the two lock nuts (G).

Step 5: Attach the glass shade(L) onto fixture(K) using socket ring(E).

Step 6: Install the bulb(not included). Don't exceed the maximum capacity recommended on the fixture).

CLEANING

To clean, wipe fixture with a soft and dry cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

Line art shown may not exactly match the fixture enclosed. However, the installations do apply to this fixture.

ITEM NO:2821-BN/2821-MB

