



# ASSEMBLY INSTRUCTIONS




## +Parts Included

① Frame seat (1 pc)




② Leg frame (1 pc)



**+Do Not Use  
Power Tools**




**+Suggested  
Adults**



## +Parts Included

A. Bolt  
Ø6x20mm (8 pcs)



B. Spring Washer  
Ø6xØ12mm (8 pcs)



### NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

### 1 IMPORTANT SAFETY INFORMATION

- Do not** assemble the product if the parts arrived damaged.
- Do not** assemble if Hardware parts are missing.


### 2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

C. Flat Washer  
Ø6xØ19mm (8 pcs)




D. Allen Key (1 pc)



# ASSEMBLY INSTRUCTIONS

①



②

