

ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 4075

ITEM DESCRIPTION : 4 DOOR SIDEBOARD



1

Reverse the cabinet top & place the leg as shown & align the leg to match the apron.



3

Fix the other legs in the similar way



Twist the leg into the slot first. Then place the bolt & washer in the cut out & tighten it with allen key provided as in Fig1.

2



4

Reverse the cabinet straight. Now your cabinet is ready for use.



